

Configuration Manual

for v2 Routers



Used symbols



Danger – important notice, which may have an influence on the user's safety or the function of the device.



Attention – notice on possible problems, which can arise in specific cases.



Information, notice – information, which contains useful advice or special interest.

Firmware version

Actual version of firmware is 5.1.0 (March 17, 2015).

GPL licence

Source codes under GPL licence are available free of charge by sending an email to:

info@conel.cz.

Router version

Properties and settings of router associated with the GSM connection is not available in industrial router XR5i v2.

PPPoE configuration item is only available on the industrial router XR5i v2, used to set the PPPoE connection over Ethernet.



Contents

1 Configuration over web	1
1.1 Secured access to web configuration	2
1.2 General	2
1.2.1 Mobile Connection	2
1.2.2 Primary LAN	3
1.2.3 Peripheral Ports	3
1.2.4 System Information	3
1.3 Mobile WAN status	4
1.4 WiFi	7
1.5 WiFi Scan	8
1.6 Network status	10
1.7 DHCP status	12
1.8 IPsec status	13
1.9 DynDNS status	13
1.10 System Log	14
1.11 LAN configuration	15
1.12 VRRP configuration	21
1.13 Mobile WAN configuration	23
1.13.1 Connection to mobile network	23
1.13.2 DNS address configuration	24
1.13.3 Check connection to mobile network configuration	24
1.13.4 Data limit configuration	25
1.13.5 Switch between SIM cards configuration	26
1.13.6 Dial-In access configuration	28
1.13.7 PPPoE bridge mode configuration	28
1.14 PPPoE Configuration	31
1.15 WiFi configuration	32
1.16 WLAN configuration	36
1.17 Backup Routes	38
1.18 Firewall configuration	39
1.19 NAT configuration	43
1.20 OpenVPN tunnel configuration	47
1.21 IPsec tunnel configuration	52
1.22 GRE tunnels configuration	57
1.23 L2TP tunnel configuration	60
1.24 PPTP tunnel configuration	62
1.25 DynDNS client configuration	64
1.26 NTP client configuration	65
1.27 SNMP configuration	66

1.28 SMTP Configuration	71
1.29 SMS configuration	72
1.29.1 Send SMS	75
1.30 Expansion port configuration	80
1.31 USB port configuration	84
1.32 Startup script	88
1.33 Up/Down script	89
1.34 Automatic update configuration	90
1.35 User modules	92
1.36 Change profile	93
1.37 Change password	94
1.38 Set real time clock	94
1.39 Set SMS service center address	94
1.40 Unlock SIM card	95
1.41 Send SMS	95
1.42 Backup configuration	96
1.43 Restore configuration	96
1.44 Update firmware	96
1.45 Reboot	97
2 Configuration over Telnet	98

List of Figures

1	Web configuration	1
2	Mobile WAN status	6
3	WiFi Status	7
4	WiFi Scan	9
5	Network status	11
6	DHCP status	12
7	IPsec status	13
8	DynDNS status	13
9	System Log	15
10	Example program syslogd start with the parameter -r	15
11	Topology of example LAN configuration 1	17
12	Example LAN configuration 1	18
13	Topology of example LAN configuration 2	19
14	Example LAN configuration 2	19
15	Topology of example LAN configuration 3	20
16	Example LAN configuration 3	20
17	Topology of example VRRP configuration	22
18	Example VRRP configuration — main router	22
19	Example VRRP configuration — backup router	22
20	Mobile WAN configuration	29
21	Example of Mobile WAN configuration 1	30
22	Example of Mobile WAN configuration 2	30
23	Example of Mobile WAN configuration 3	30
24	PPPoE configuration	31
25	WiFi konfigurace	35
26	WLAN configuration	37
27	Backup Routes	38
28	Firewall configuration	41
29	Topology of example firewall configuration	42
30	Example firewall configuration	42
31	Topology of example NAT configuration 1	44
32	Example NAT configuration 1	45
33	Topology of example NAT configuration 2	46
34	Example NAT configuration 2	46
35	OpenVPN tunnels configuration	47
36	OpenVPN tunnel configuration	50
37	Topology of example OpenVPN configuration	51
38	IPsec tunnels configuration	52
39	IPsec tunnels configuration	56
40	Topology of example IPsec configuration	57

41	GRE tunnels configuration	58
42	GRE tunnel configuration	59
43	Topology of GRE tunnel configuration	59
44	L2TP tunnel configuration	60
45	Topology of example L2TP tunnel configuration	61
46	PPTP tunnel configuration	62
47	Topology of example PPTP tunnel configuration	63
48	Example of DynDNS configuration	64
49	Example of NTP configuration	65
50	Example of SNMP configuration	69
51	Example of the MIB browser	70
52	Example of the SMTP client configuration	71
53	Example of SMS configuration 1	76
54	Example of SMS configuration 2	77
55	Example of SMS configuration 3	78
56	Example of SMS configuration 4	79
57	Expansion port configuration	82
58	Example of expansion port configuration 1	82
59	Example of expansion port configuration 2	83
60	USB configuration	86
61	Example of USB port configuration 1	86
62	Example of USB port configuration 2	87
63	Startup script	88
64	Example of Startup script	88
65	Up/Down script	89
66	Example of Up/Down script	89
67	Example of automatic update 1	91
68	Example of automatic update 2	91
69	User modules	92
70	Added user module	92
71	Change profile	93
72	Change password	94
73	Set real time clock	94
74	Set SMS service center address	95
75	Unlock SIM card	95
76	Send SMS	95
77	Restore configuration	96
78	Update firmware	96
79	Reboot	97

List of Tables

1	Mobile connection	3
2	Peripheral Ports	3
3	System Information	4
4	Mobile Network Information	5
5	Description of period	5
6	Mobile Network Statistics	5
7	Traffic statistics	6
8	State information about access point	7
9	State information about connected clients	7
10	Information about neighbouring WiFi networks	8
11	Description of interface in network status	10
12	Description of information in network status	11
13	DHCP status description	12
14	Configuration of network interface	16
15	Configuration of dynamic DHCP server	17
16	Configuration of static DHCP server	17
17	VRRP configuration	21
18	Check connection	21
19	Mobile WAN connection configuration	23
20	Check connection to mobile network configuration	25
21	Data limit configuration	25
22	Default and backup SIM configuration	26
23	Switch between SIM card configurations	27
24	Switch between SIM card configurations	27
25	Dial-In access configuration	28
26	PPPoE configuration	31
27	WiFi configuration	35
28	WLAN configuration	36
29	Configuration of DHCP server	37
30	Backup Routes	39
31	Filtering of incoming packets	40
32	Forwarding filtering	41
33	NAT configuration	43
34	Configuration of send all incoming packets	43
35	Remote access configuration	44
36	Overview OpenVPN tunnels	47
37	OpenVPN tunnels configuration	49
38	Example OpenVPN configuration	51
39	Overview IPsec tunnels	52
40	IPsec tunnel configuration	54

41	Example IPsec configuration	57
42	Overview GRE tunnels	58
43	GRE tunnel configuration	58
44	Example GRE tunnel configuration	59
45	L2TP tunnel configuration	60
46	Example L2TP tunnel configuration	61
47	PPTP tunnel configuration	62
48	Example PPTP tunnel configuration	63
49	DynDNS configuration	64
50	NTP configuration	65
51	SNMP agent configuration	66
52	SNMPv3 configuration	66
53	SNMP configuration (MBUS extension)	67
54	SNMP configuration (R-SeeNet)	67
55	Object identifier for binary input and output	67
56	Object identifier for CNT port	68
57	Object identifier for M-BUS port	68
58	SMTP client configuration	71
59	Send SMS configuration	73
60	Control via SMS configuration	73
61	Control SMS	74
62	Send SMS on serial PORT1 configuration	74
63	Send SMS on serial PORT2 configuration	74
64	Send SMS on ethernet PORT1 configuration	74
65	List of AT commands	75
66	Expansion PORT configuration 1	80
67	Expansion PORT configuration 2	81
68	CD signal description	81
69	DTR signal description	81
70	USB port configuration 1	84
71	USB PORT configuration 2	85
72	CD signal description	85
73	DTR signal description	85
74	Automatic update configuration	90
75	User modules	93
76	Telnet commands	99

1. Configuration over web browser



Attention! If the SIM card is not inserted in the router, then wireless transmissions will not work. The inserted SIM card must have activated GPRS. Insert the SIM card when the router is switched-off.

For monitoring, configuring and managing the router use web interface, which can be invoked by entering the IP address of the router into your browser. The default IP address of the router is 192.168.1.1. Configuration may be performed only by the user "root" with initial password "root".

The left part of the web interface contains the menu with pages for monitoring (*Status*), *Configuration*, *Customization* and *Administration* of the router.

Name and *Location* items displays the name and location of the router filled in the SNMP configuration (see SNMP Configuration).



For increased safety of the network managed by the router must be changed the default router password. If the router's default password is set, the **Change password** item is highlighted in red.

Status	General Status
<ul style="list-style-type: none"> General Mobile WAN Network DHCP IPsec DynDNS System Log 	<p>Mobile Connection</p> <p>SIM Card : Primary IP Address : 10.0.1.228 Rx Data : 104 B Tx Data : 208 B Uptime : 0 days, 0 hours, 1 minute</p> <p>» More Information «</p> <p>Primary LAN</p> <p>IP Address : 192.168.1.1 / 255.255.255.0 MAC Address : 02:00:00:00:00:04 Rx Data : 194.4 KB Tx Data : 43.8 KB</p> <p>» More Information «</p> <p>Peripheral Ports</p> <p>Expansion Port 1 : RS232 Expansion Port 2 : None Binary Input : Off Binary Output : Off</p> <p>System Information</p> <p>Firmware Version : 3.0.7 (2013-07-08) Serial Number : 5193072 Profile : Standard Supply Voltage : 12.4 V Temperature : 36 °C Time : 2013-07-08 12:47:38 Uptime : 0 days, 0 hours, 1 minute</p>
<p>Configuration</p> <ul style="list-style-type: none"> LAN VRRP Mobile WAN Backup Routes Firewall NAT OpenVPN IPsec GRE L2TP PPTP DynDNS NTP SNMP SMTP SMS Expansion Port 1 Expansion Port 2 USB Port Startup Script Up/Down Script Automatic Update 	
<p>Customization</p> <ul style="list-style-type: none"> User Modules 	
<p>Administration</p> <ul style="list-style-type: none"> Change Profile Change Password Set Real Time Clock Set SMS Service Center Unlock SIM Card Send SMS Backup Configuration Restore Configuration Update Firmware Reboot 	

Figure 1: Web configuration



After green LED starts to blink it is possible to restore initial settings of the router by pressing button RST on front panel. If press button RST, configuration is restored to default and it is reboot (green LED will be on).

1.1 Secured access to web configuration

To the web configuration can be accessed via a secure HTTPS protocol. In the event of a default router IP address is a secure router configuration accessed by entering address `https://192.168.1.1` in the web browser. The first approach is the need to install a security certificate. If your browser reports a disagreement in the domain, this message can be prevented use the following procedure.

Since the domain name in the certificate is given the MAC address of the router (such separators are used dashes instead of colons), it is necessary to access the router under this domain name. For access to the router via a domain name, it is adding a DNS record in the DNS table, the operating system.

- Editing `/etc/hosts` (Linux/Unix)
- Editing `C:\WINDOWS\system32\drivers\etc\hosts` (Windows XP)
- Configuring your own DNS server

In addition to configuring the router with MAC address `00:11:22:33:44:55` is accessed to secure configuration by typing address `https://00-11-22-33-44-55` in the web browser. The first approach is the need to install a security certificate.



When using self signing certificate must upload your files and `https_cert` `https_key` directory `/etc/certs` in the router.

1.2 General

A summary of basic information about the router and its activities can be invoked by selecting the *General* item. This page is also displayed when you login to the web interface. Information is divided into a several of separate blocks according to the type of router activity or the properties area – *Mobile Connection*, *Primary LAN*, *Peripherals Ports* and *System Information*. If your router is equipped with WIFI expansion port, there is also *WIFI* section.

1.2.1 Mobile Connection

Item	Description
SIM Card	Identification of the SIM card (<i>Primary</i> or <i>Secondary</i>)
Interface	Defines the interface
Flags	Displays network interface flags
IP Address	IP address of the interface

Continued on next page

Continued from previous page

Item	Description
MTU	Maximum packet size that the equipment is able to transmit
Rx Data	Total number of received bytes
Rx Packets	Received packets
Rx Errors	Erroneous received packets
Rx Dropped	Dropped received packets
Rx Overruns	Lost received packets because of overload
Tx Data	Total number of sent bytes
Tx Packets	Sent packets
Tx Errors	Erroneous sent packets
Tx Dropped	Dropped sent packets
Tx Overruns	Lost sent packets because of overload
Uptime	Indicates how long the connection to mob. network is established

Table 1: Mobile connection

1.2.2 Primary LAN

Items displayed in this part have the same meaning as items in the previous part. Moreover, there is information about the MAC address of the router (*MAC Address* item).

1.2.3 Peripheral Ports

Item	Description
Expansion Port 1	Expansion port fitted to the position 1 (<i>None</i> indicates that this position is equipped with no port)
Expansion Port 2	Expansion port fitted to the position 2 (<i>None</i> indicates that this position is equipped with no port)
Binary Input	State of binary input
Binary Output	State of binary output

Table 2: Peripheral Ports

1.2.4 System Information

Item	Description
Firmware Version	Information about the firmware version
Serial Number	Serial number of the router (in case of <i>N/A</i> is not available)

Continued on next page

Continued from previous page

Item	Description
Profile	Current profile – standard or alternative profiles (profiles are used for example to switch between different modes of operation)
Supply Voltage	Supply voltage of the router
Temperature	Temperature in the router
Time	Current date and time
Uptime	Indicates how long the router is used

Table 3: System Information

1.3 Mobile WAN status



This item is not available for industrial router XR5i v2.

The *Mobile WAN* menu item contains current information about connections to the mobile network. The first part of this page (*Mobile Network Information*) displays basic information about mobile network in which the router is operated. There is also information about the module, which is mounted in the router.

Item	Description
Registration	State of the network registration
Operator	Specifies the operator in whose network the router is operated
Technology	Transmission technology
PLMN	Code of operator
Cell	Cell to which the router is connected
LAC	Location Area Code – unique number assigned to each location area
Channel	Channel on which the router communicates
Signal Strength	Signal strength of the selected cell
Signal Quality	Signal quality of the selected cell: <ul style="list-style-type: none"> • EC/IO for UMTS and CDMA (it's the ratio of the signal received from the pilot channel – EC – to the overall level of the spectral density, ie the sum of the signals of other cells – IO) • RSRQ for LTE technology (Defined as the ratio $\frac{N \times RSRP}{RSSI}$) • For EDGE technology (router ER75i v2) value is not available

Continued on next page

Continued from previous page

Item	Description
CSQ	Cell Signal Quality, relative value is given by RSSI (dBm). 2–9 range means Marginal, 10–14 range means OK, 15–16 range means Good, 20–30 range means excellent.
Neighbours	Signal strength of neighboring hearing cells
Manufacturer	Module manufacturer
Model	Type of module
Revision	Revision of module
IMEI	IMEI (International Mobile Equipment Identity) number of module
ESN	ESN (Electronic Serial Number) number of module (for CDMA routers)
MEID	MEID number of module
ICCID	Integrated Circuit Card Identifier is international and unique serial number of the SIM card.

Table 4: Mobile Network Information



Highlighted in red adjacent cells have a close signal quality, which means that there is imminence of frequent switching between the current and the highlighted cell.

The next section of this window displays information about the quality of the connection in each period.

Period	Description
Today	Today from 0:00 to 23:59
Yesterday	Yesterday from 0:00 to 23:59
This week	This week from Monday 0:00 to Sunday 23:59
Last week	Last week from Monday 0:00 to Sunday 23:59
This period	This accounting period
Last period	Last accounting period

Table 5: Description of period

Item	Description
Signal Min	Minimal signal strength
Signal Avg	Average signal strength
Signal Max	Maximal signal strength
Cells	Number of switch between cells
Availability	Availability of the router via the mobile network (expressed as a percentage)

Table 6: Mobile Network Statistics



Tips for *Mobile Network Statistics* table:

- Availability is expressed as a percentage calculated by the ratio of time the connection to mobile network was established to the time the router was turned on.
- After you place your cursor on the maximum or minimum signal strength, the last time when the router reached this signal strength is displayed.

In the middle part of this page is displayed information about transferred data and number of connections for both SIM card (for each period).

Item	Description
RX data	Total volume of received data
TX data	Total volume of sent data
Connections	Number of connection to mobile network establishment

Table 7: Traffic statistics

The last part (*Mobile Network Connection Log*) informs about the mobile network connection and problems in establishment.

Mobile WAN Status

Mobile Network Information

Registration : Home Network

Operator : T-Mobile CZ

Technology : EDGE

PLMN : 23001

Cell : 69A6

LAC : 353E

Channel : 30

Signal Strength : -71 dBm

Neighbours : -83 dBm (80), -81 dBm (57), -93 dBm (59)

> More Information <

Mobile Network Statistics

Signal Min : Today -108 dBm Yesterday -121 dBm This Week -121 dBm Last Week -121 dBm This Period -121 dBm Last Period -121 dBm

Signal Avg : -71 dBm -71 dBm -71 dBm -69 dBm -70 dBm -85 dBm

Signal Max : -65 dBm -65 dBm -65 dBm -63 dBm -63 dBm -58 dBm

Cells : 15 261 525 206 730 962

Availability : 99.7% 99.7% 99.7% 99.7% 99.7% 97.5%

Traffic Statistics for Primary SIM card

Rx Data : Today 12 KB Yesterday 21 KB This Week 19402 KB Last Week 6366 KB This Period 25768 KB Last Period 18868 KB

Tx Data : 13 KB 19 KB 5167 KB 3382 KB 8549 KB 3726 KB

Connections : 2 7 20 36 56 49

Traffic Statistics for Secondary SIM card

Rx Data : Today 0 KB Yesterday 0 KB This Week 0 KB Last Week 0 KB This Period 0 KB Last Period 0 KB

Tx Data : 0 KB 0 KB 0 KB 0 KB 0 KB 0 KB

Connections : 0 0 0 0 0 0

Mobile Network Connection Log

2013-07-10 11:52:40 Connection successfully established.

2013-07-10 21:17:21 Terminated by signal.

2013-07-10 21:18:01 Connection successfully established.

2013-07-11 08:39:20 Terminated by signal.

2013-07-11 08:40:01 Connection successfully established.

2013-07-11 09:22:24 Terminated by signal.

2013-07-11 09:23:08 Connection successfully established.

Figure 2: Mobile WAN status

1.4 WiFi



This item is available only if the router is equipped with a WiFi module.

After selecting the *WiFi* item in the main menu of the web interface, information about WiFi access point (AP) and associated stations is displayed.

Item	Description
hostapd state dump	Time to which statistical data relates
num_sta	Number of connected stations
num_sta_non_erp	Number of connected stations using 802.11b in 802.11g BSS connection
num_sta_no_short_slot_time	Number of stations not supporting the Short Slot Time
num_sta_no_short_preamble	Number of stations not supporting the Short Preamble

Table 8: State information about access point

For each connected client are displayed more detailed information. Most of them has an internal character, so let us mention only the following:

Item	Description
STA	MAC address of connected device (station)
AID	Identifier of connected device (1 – 2007). If 0 is displayed, the station is not currently connected.

Table 9: State information about connected clients

```

WiFi Status
WiFi AP Status

hostapd state dump - Mon Apr  7 12:49:50 2014
num_sta=1 num_sta_non_erp=0 num_sta_no_short_slot_time=1
num_sta_no_short_preamble=0

STA=20:02:af:2a:8f:b1
AID=1 flags=0xa3 [AUTH][ASSOC][AUTHORIZED][SHORT_PREAMBLE]
capability=0x21 listen_interval=10
supported_rates=82 84 0b 16
timeout_next=NULLFUNC POLL
  
```

Figure 3: WiFi Status

1.5 WiFi Scan



This item is available only if the router is equipped with a WiFi module.

After selecting the *WiFi Scan* item in the menu of the web interface, scanning of neighbouring WiFi networks and subsequent printing of results are invoked. **Scanning can be performed only if the access point (WiFi AP) is off.**

item	Description
BSS	MAC address of access point (AP)
TSF	A Timing Synchronization Function (TSF) keeps the timers for all stations in the same Basic Service Set (BSS) synchronized. All stations shall maintain a local TSF timer.
freq	Frequency band of WiFi network [kHz]
beacon interval	Period of time synchronization
capability	List of access point (AP) properties
signal	Signal level of access point (AP)
last seen	Last response time of access point (AP)
SSID	Identifier of access point (AP)
Supported rates	Supported rates of access point (AP)
DS Parameter set	The channel on which access point (AP) broadcasts
ERP	Extended Rate PHY – information element providing backward compatibility
Extended supported rates	Supported rates of access point (AP) that are beyond the scope of eight rates mentioned in <i>Supported rates</i> item
RSN	Robust Secure Network – The protocol for establishing a secure communication through wireless network 802.11

Table 10: Information about neighbouring WiFi networks




Figure 4: WiFi Scan

1.6 Network status

To view system information about the router operation, select the *Network* item in the main menu. The upper part of the window displays detailed information about active interfaces:

Interface	Description
eth0, eth1	Network interfaces (ethernet connection)
ppp0	Interface (active connection to GPRS/EDGE)
tun0	OpenVPN tunnel interface
ipsec0	IPSec tunnel interface
gre1	GRE tunnel interface
usb0	USB interface

Table 11: Description of interface in network status

By each of the interfaces is then shown the following information:

Item	Description
HWaddr	Hardware (unique) address of networks interface
inet	IP address of interface
P-t-P	IP address second ends connection
Bcast	Broadcast address
Mask	Mask of network
MTU	Maximum packet size that the equipment is able to transmit
Metric	Number of routers, over which packet must go through
RX	<ul style="list-style-type: none"> • packets – received packets • errors – number of errors • dropped – dropped packets • overruns – incoming packets lost because of overload • frame – wrong incoming packets because of incorrect packet size
TX	<ul style="list-style-type: none"> • packets – transmit packets • errors – number of errors • dropped – dropped packets • overruns – outgoing packets lost because of overload • carrier – wrong outgoing packets with errors resulting from the physical layer

Continued on next page

Continued from previous page

Item	Description
collisions	Number of collisions on physical layer
txqueuelen	Length of front network device
RX bytes	Total number of received bytes
TX bytes	Total number of transmitted bytes

Table 12: Description of information in network status

It is possible to read status of connection to mobile network from the network information. If the connection to mobile network is active, then it is in the system information shown as a ppp0 interface.



For industrial router XR5i v2, interface ppp0 indicates PPPoE connection.

Network Status						
Interfaces						
eth0	Link encap:Ethernet HWaddr 00:11:22:33:44:55 inet addr:192.168.1.1 Bcast:192.168.1.255 Mask:255.255.255.0 UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1 RX packets:407 errors:0 dropped:0 overruns:0 frame:0 TX packets:461 errors:0 dropped:0 overruns:0 carrier:0 collisions:0 txqueuelen:32 RX bytes:51793 (50.5 KB) TX bytes:321807 (314.2 KB) Interrupt:23					
ppp0	Link encap:Point-Point Protocol inet addr:10.169.80.137 P-t-P:10.0.0.1 Mask:255.255.255.255 UP POINTOPOINT RUNNING NOARP MULTICAST MTU:1500 Metric:1 RX packets:35 errors:0 dropped:0 overruns:0 frame:0 TX packets:46 errors:0 dropped:0 overruns:0 carrier:0 collisions:0 txqueuelen:3 RX bytes:7772 (7.5 KB) TX bytes:8716 (8.5 KB)					
Route Table						
Destination	Gateway	Genmask	Flags	Metric	Ref	Use Iface
10.0.0.1	0.0.0.0	255.255.255.255	UH	0	0	0 ppp0
192.168.1.0	0.0.0.0	255.255.255.0	U	0	0	0 eth0
0.0.0.0	10.0.0.1	0.0.0.0	UG	0	0	0 ppp0

Figure 5: Network status

1.7 DHCP status

Information on the activities of the DHCP server can be accessed by selecting the *DHCP status* item.

DHCP status informs about activities DHCP server. The DHCP server provides automatic configuration of devices connected to the network managed router. DHCP server assigns to each device's IP address, netmask, default gateway (IP address of router) and DNS server (IP address of router).

For each configuration, the DHCP status window displays the following information.

Item	Description
lease	Assigned IP address
starts	Time of assignation of IP address
ends	Time of termination IP address validity
hardware ethernet	Hardware MAC (unique) address
uid	Unique ID
client-hostname	Computer name

Table 13: DHCP status description



In the extreme case, the DHCP status can display two records for one IP address. That could have been caused by resetting of network cards.

DHCP Status	
Active DHCP Leases (Primary LAN)	
lease 192.168.1.2 {	
starts 1 2011/01/17 08:08:37;	
ends 1 2011/01/17 08:18:37;	
hardware ethernet 00:1d:92:25:72:33;	
uid 01:00:1d:92:25:72:33;	
client-hostname "felgr2";	
}	
Active DHCP Leases (WLAN)	
No active dynamic DHCP leases.	

Figure 6: DHCP status

Note: Starting with firmware 4.0.0, records in the *DHCP status* window are divided into two separate parts – *Active DHCP Leases (Primary LAN)* and *Active DHCP Leases (WLAN)*.

1.8 IPsec status

Information on actual IPsec tunnel state can be called up in option *IPsec* in the menu.

After correct build the IPsec tunnel, status display *IPsec SA established* (highlighted in red) in IPsec status information. Other information is only internal character.

IPsec Status	
IPsec Tunnels Information	
<pre> interface eth0/eth0 192.168.2.250 interface ppp0/ppp0 10.0.0.132 %myid = (none) debug none "ipsecl": 192.168.2.0/24===10.0.0.132...10.0.1.228===192.168.1.0/24; erouted; eroute owner: #2 "ipsecl": myip=unset; hisip=unset; myup=/etc/scripts/updown; hisup=/etc/scripts/updown; "ipsecl": ike_life: 3600s; ipsec_life: 3600s; rekey_margin: 540s; rekey_fuzz: 100%; keyingtries: 0 "ipsecl": policy: PSK+ENCRYPT+TUNNEL+UP; prio: 24,24; interface: ppp0; "ipsecl": newest ISAKMP SA: #1; newest IPsec SA: #2; "ipsecl": IKE algorithm newest: AES_CBC_128-SHA1-MODP2048 #2: "ipsecl":500 STATE_QUICK_I2 (sent QI2, IPsec SA established); EVENT_SA_REPLACE in 2708s; newest IPSEC; erout #2: "ipsecl" esp.d07e3080@10.0.1.228 esp.783be7ee@10.0.0.132 tun.0@10.0.1.228 tun.0@10.0.0.132 ref=0 refhim=4294 #1: "ipsecl":500 STATE_MAIN_I4 (ISAKMP SA established); EVENT_SA_REPLACE in 2733s; newest ISAKMP; lastdpd=-1s(se </pre>	

Figure 7: IPsec status

1.9 DynDNS status

The result of updating DynDNS record on the server www.dyndns.org can be invoked by pressing the *DynDNS* item in the menu.

DynDNS Status	
Last DynDNS Update Status	
<p>DynDNS record successfully updated.</p>	

Figure 8: DynDNS status

In detecting the status of updates DynDNS record are possible following message:

- DynDNS client is disabled.
- Invalid username or password.
- Specified hostname doesn't exist.
- Invalid hostname format.
- Hostname exists, but not under specified username.
- No update performed yet.
- DynDNS record is already up to date.
- DynDNS record successfully update.
- DNS error encountered.
- DynDNS server failure.



For correct function DynDNS, SIM card of router must have assigned public IP address.

1.10 System Log

In case of any problems with connection to GPRS it is possible to view the system log by pressing the *System Log* menu item. In the window, are displayed detailed reports from individual applications running in the router. Use the *Save Log* button to save the system log to a connected computer. The second button – *Save Report* – is used for creating detailed report (generates all support needed information in one file).

The Syslog default size is 1000 lines. After reaching 1000 lines create a new file for storing system log. After completion of the 1000 lines in the second file, the first file is deleted and creates a new one.

Program syslogd can be started with two options that modifies its behavior. Option "-s" followed by decimal number set maximal number of lines in one log file. Option "-r" followed by hostname or IP address enable logging to remote syslog daemon. In the Linux must be enabled remote logging on the target computer. Typically running syslogd with the parameter "-r". On Windows must be installed the syslog server (for example Syslog Watcher). For starting syslogd with these options you could modify script "/etc/init.d/syslog" or add lines "killall syslogd" and "syslogd <options> &" into Startup Script.




Figure 9: System Log

Example of logging into the remote daemon at 192.168.2.115:




Figure 10: Example program syslogd start with the parameter -r

1.11 LAN configuration

To enter the network configuration, select the *LAN* menu item. ETH network set in *Primary LAN* configuration, expansion PORT ETH set in *Secondary LAN* configuration.

Item	Description
DHCP Client	<ul style="list-style-type: none"> disabled – The router does not allow automatic allocation IP address from a DHCP server in LAN network. enabled – The router allows automatic allocation IP address from a DHCP server in LAN network.

Continued on next page

Continued from previous page

Item	Description
IP address	Fixed set IP address of network interface ETH.
Subnet Mask	IP address of Subnet Mask.
Bridged	<ul style="list-style-type: none"> • no – router is not used as a bridge (default) • yes – router is used as a bridge
Media type	<ul style="list-style-type: none"> • Auto-negation – The router selects the speed of communication of network options. • 100 Mbps Full Duplex – The router communicates at 100Mbps, in the full duplex mode. • 100 Mbps Half Duplex – The router communicates at 100Mbps, in the half duplex mode. • 10 Mbps Full Duplex – The router communicates at 10Mbps, in the full duplex mode. • 10 Mbps Half Duplex – The router communicates at 10Mbps, in the half duplex mode.
Default Gateway	IP address of router default gateway. When entering IP address of default gateway, all packets for which the record was not found in the routing table, sent to this address.
DNS server	IP address of DNS server of router. Address where they are forwarded to all DNS questions on the router.

Table 14: Configuration of network interface



The router considers the last address in the network range to be broadcast address, regardless of the address is set as a broadcast or not. Connection (ping) to the broadcast address does not work.

Default Gateway and *DNS Server* items are used only if the *DHCP Client* item is set to a value *disabled* and if the Primary or Secondary LAN is selected by Backup routes system as a default route (selection algorithm is described in section 1.17 *Backup Routes*).

There can be only one active bridge on the router at the moment. Only parameters DHCP Client, IP address and Subnet Mask can be used to configure bridge. Primary LAN has got higher priority in this respect when both interfaces (eth0, eth1) are added to the bridge. Other interfaces (wlan0 – wifi) can be added (or deleted) to (from) existing bridge at any moment. Moreover, the bridge can be created on demand of such interfaces but not configured by their respective parameters.

DHCP server assigns IP address, gateway IP address (IP address of the router) and IP address of the DNS server (IP address of the router) to the connected clients. If these values are filled-in by the user in the configuration form, they are preferred.

DHCP server supports static and dynamic assignment of IP addresses. Dynamic DHCP server assigns clients IP addresses from a defined address space. Static DHCP assigns IP addresses that correspond to the MAC addresses of connected clients.

Item	Description
Enable dynamic DHCP leases	If this option is checked, dynamic DHCP server is enable.
IP Pool Start	Start IP addresses space to be allocated to the DHCP clients.
IP Pool End	End IP addresses space to be allocated to the DHCP clients.
Lease time	Time in seconds, after which the client can use IP address.

Table 15: Configuration of dynamic DHCP server

Item	Description
Enable static DHCP leases	If this option is checked, static DHCP server is enable.
MAC Address	MAC address of a DHCP client.
IP Address	Assigned IP address.

Table 16: Configuration of static DHCP server



It is important not to overlap ranges of static allocated IP address with address allocated by the dynamic DHCP. Then risk collision of IP addresses and incorrect function of network.

Example of the network interface with dynamic DHCP server:

- The range of dynamic allocated addresses from 192.168.1.2 to 192.168.1.4.
- The address is allocated 600 second (10 minutes).




Figure 11: Topology of example LAN configuration 1

LAN Configuration			
	Primary LAN	Secondary LAN	
DHCP Client	<input type="text" value="disabled"/>	<input type="text" value="enabled"/>	
IP Address	<input type="text" value="192.168.1.1"/>	<input type="text"/>	
Subnet Mask	<input type="text" value="255.255.255.0"/>	<input type="text"/>	
Bridged	<input type="text" value="no"/>	<input type="text" value="no"/>	
Media Type	<input type="text" value="auto-negotiation"/>	<input type="text" value="auto-negotiation"/>	
Default Gateway	<input type="text"/>	<input type="text"/>	
DNS Server	<input type="text"/>	<input type="text"/>	
<input checked="" type="checkbox"/> Enable dynamic DHCP leases			
IP Pool Start	<input type="text" value="192.168.1.2"/>		
IP Pool End	<input type="text" value="192.168.1.4"/>		
Lease Time	<input type="text" value="600"/>	sec	
<input type="checkbox"/> Enable static DHCP leases			
MAC Address	IP Address		
<input type="text"/>	<input type="text"/>		
<input type="text"/>	<input type="text"/>		
<input type="text"/>	<input type="text"/>		
<input type="text"/>	<input type="text"/>		
<input type="text"/>	<input type="text"/>		
<input type="text"/>	<input type="text"/>		
<input type="button" value="Apply"/>			

Figure 12: Example LAN configuration 1

Example of the network interface with dynamic and static DHCP server:

- The range of allocated addresses from 192.168.1.2 to 192.168.1.4.
- The address is allocated 10 minutes.
- Client's with MAC address 01:23:45:67:89:ab has IP address 192.168.1.10.
- Client's with MAC address 01:54:68:18:ba:7e has IP address 192.168.1.11.




Figure 13: Topology of example LAN configuration 2

LAN Configuration			
	Primary LAN		Secondary LAN
DHCP Client	disabled		enabled
IP Address	192.168.1.1		
Subnet Mask	255.255.255.0		
Bridged	no		no
Media Type	auto-negotiation		auto-negotiation
Default Gateway			
DNS Server			
<input checked="" type="checkbox"/> Enable dynamic DHCP leases			
IP Pool Start	192.168.1.2		
IP Pool End	192.168.1.4		
Lease Time	600 sec		
<input checked="" type="checkbox"/> Enable static DHCP leases			
MAC Address	IP Address		
01:23:45:67:89:ab	192.168.1.10		
01:54:68:18:ba:7e	192.168.1.11		
<input type="button" value="Apply"/>			

Figure 14: Example LAN configuration 2

Example of the network interface with default gateway and DNS server:

- Default gateway IP address is 192.168.1.20
- DNS server IP address is 192.168.1.20




Figure 15: Topology of example LAN configuration 3

LAN Configuration			
	Primary LAN		Secondary LAN
DHCP Client	<input type="text" value="disabled"/>	<input type="text" value="enabled"/>	
IP Address	<input type="text" value="192.168.1.1"/>	<input type="text"/>	
Subnet Mask	<input type="text" value="255.255.255.0"/>	<input type="text"/>	
Bridged	<input type="text" value="no"/>	<input type="text" value="no"/>	
Media Type	<input type="text" value="auto-negotiation"/>	<input type="text" value="auto-negotiation"/>	
Default Gateway	<input type="text" value="192.168.1.20"/>	<input type="text"/>	
DNS Server	<input type="text" value="192.168.1.20"/>	<input type="text"/>	
<input checked="" type="checkbox"/> Enable dynamic DHCP leases			
IP Pool Start	<input type="text" value="192.168.1.2"/>		
IP Pool End	<input type="text" value="192.168.1.4"/>		
Lease Time	<input type="text" value="600"/>	sec	
<input type="checkbox"/> Enable static DHCP leases			
MAC Address	IP Address		
<input type="text"/>	<input type="text"/>		
<input type="text"/>	<input type="text"/>		
<input type="text"/>	<input type="text"/>		
<input type="text"/>	<input type="text"/>		
<input type="text"/>	<input type="text"/>		
<input type="text"/>	<input type="text"/>		
<input type="button" value="Apply"/>			

Figure 16: Example LAN configuration 3

1.12 VRRP configuration

To enter the VRRP configuration select the *VRRP* menu item. VRRP protocol (Virtual Router Redundancy Protocol) is a technique, by which it is possible to forward routing from main router to backup router in the case of the main router failure. If the *Enable VRRP* is checked, then it is possible to set the following parameters.

Item	Description
Virtual Server IP Address	This parameter sets virtual server IP address. This address should be the same for both routers. A connected device sends its data via this virtual address.
Virtual Server ID	Parameter Virtual Server ID distinguishes one virtual router on the network from others. Main and backup routers must use the same value for this parameter.
Host Priority	The router, with higher priority set by the parameter Host Priority, is the main router. According to RFC 2338 the main router has the highest possible priority - 255. The backup router has priority in range 1 – 254 (init value is 100). The priority value equals 0 is not allowed.

Table 17: VRRP configuration

It is possible to set *Check connection* flag in the second part of the window. The currently active router (main/backup) will send testing messages to defined *Ping IP Address* at periodic time intervals (*Ping Interval*) with setting time of waiting for answer (*Ping Timeout*). The function check connection is used as a supplement of VRRP standard with the same final result. If there are no answers from remote devices (*Ping IP Address*) for a defined number of probes (*Ping Probes*), then connection is switched to the other line.

Item	Description
Ping IP Address	Destinations IP address ping queries. Address can not specify as domain name.
Ping Interval	Time intervals between the outgoing pings.
Ping Timeout	Time to wait to answer.
Ping Probes	Number of failed ping requests, after which the route is considered to be impassable.

Table 18: Check connection



Ping IP address is possible to use for example a DNS server of mobile operator as a test message (ping) IP address.

There's an additional way for evaluating the state of the active line. It is activated by selecting *Enable traffic monitoring* parameter. If this parameter is set and any packet different from ping is sent to the monitored line, then any answer to this packet is expected for *Ping*

Timeout. If *Ping Timeout* expires with no answer received then process of testing the active line continues the same way like in the case of standard testing process after first test message answer drops out.

Example of the VRRP protocol:




Figure 17: Topology of example VRRP configuration

VRRP Configuration	
<input checked="" type="checkbox"/> Enable VRRP	
Virtual Server IP Address	192.168.1.1
Virtual Server ID	5
Host Priority	255
<input checked="" type="checkbox"/> Check connection	
Ping IP Address	10.0.1.3
Ping Interval	10 sec
Ping Timeout	5 sec
Ping Probes	10
<input type="checkbox"/> Enable traffic monitoring	
<input type="button" value="Apply"/>	

Figure 18: Example VRRP configuration — main router

VRRP Configuration	
<input checked="" type="checkbox"/> Enable VRRP	
Virtual Server IP Address	192.168.1.1
Virtual Server ID	5
Host Priority	100
<input checked="" type="checkbox"/> Check connection	
Ping IP Address	10.0.1.3
Ping Interval	10 sec
Ping Timeout	5 sec
Ping Probes	10
<input type="checkbox"/> Enable traffic monitoring	
<input type="button" value="Apply"/>	

Figure 19: Example VRRP configuration — backup router

1.13 Mobile WAN configuration



This item is not available for industrial router XR5i v2.

The form for configuration of a connection to the mobile network can be invoked by selecting the *Mobile WAN* item in the main menu of the router web interface.

1.13.1 Connection to mobile network

If the *Create connection to mobile network* item is selected, the router automatically tries to establish connection after switching-on.

Item	Description
APN	Network identifier (Access Point Name)
Username	User name to log into the GSM network
Password	Password to log into the GSM network
Authentication	Authentication protocol in GSM network: <ul style="list-style-type: none"> • PAP or CHAP – authentication method is chosen by router • PAP – it is used PAP authentication method • CHAP – it is used CHAP authentication method
IP Address	IP address of SIM card. The user sets the IP address, only in the case IP address was assigned of the operator.
Phone Number	Telephone number to dial GPRS or CSD connection. Router as a default telephone number used *99***1 #.
Operator	This item can be defined PLNM preferred carrier code
Network type	<ul style="list-style-type: none"> • Automatic selection – router automatically selects transmission method according to the availability of transmission technology • <i>Furthermore, according to the type of router</i> – it's also possible to select a specific method of data transmission (GPRS, UMTS, ...)
PIN	PIN parameter should be set only if it requires a SIM card router. SIM card is blocked in case of several bad attempts to enter the PIN.
MRU	Maximum Receiving Unit – It's an identifier of maximum size of packet, which is possible to receive in a given environment. Default value is 1500 B. Other settings may cause incorrect transmission of data.
MTU	Maximum Transmission Unit – It's an identifier of max. size of packet, which is possible to transfer in a given environment. Default value is 1500 B. Other settings may cause incorrect transmission of data.

Table 19: Mobile WAN connection configuration



Tips for working with the *Mobile WAN* configuration form:

- If the size is set incorrectly, data transfer may not be succeeded. By setting a lower MTU it occurs to more frequent fragmentation of data, which means higher overhead and also the possibility of damage of packet during defragmentation. On the contrary, the higher value of MTU can cause that the network does not transfer the packet.
- If the *IP address* field is not filled in, the operator automatically assigns the IP address when it is establishing the connection. If filled IP address supplied by the operator, router accelerate access to the network.
- If the *APN* field is not filled in, the router automatically selects the APN by the IMSI code of the SIM card. If the PLMN (operator number format) is not in the list of APN, then default APN is "internet". The mobile operator defines APN.
- If the word *blank* is filled in the *APN* field, router interprets APN as blank.



ATTENTION:

- **If only one SIM card is plugged in the router (router has one slot for a SIM card), router switches between the APN. Router with two SIM cards switches between SIM cards.**
- **Correct PIN must be filled. For SIM cards with two APN's there will be the same PIN for both APN's. Otherwise the SIM card can be blocked by false SIM PIN.**

Items marked with an asterisk must be filled in only if this information is required by the operator (carrier).

In case of unsuccessful establishing a connection to mobile network is recommended to check the accuracy of entered data. Alternatively, try a different authentication method or network type.

1.13.2 DNS address configuration

The *DNS Settings* item is designed for easier configuration on the client side. When this item is set to the value *get from operator* router makes an attempt to automatically get an IP address of the primary and secondary DNS server from the operator. By way of contrast, *set manually* option allows you to set IP addresses of Primary DNS servers manually (using the *DNS Server* item).

1.13.3 Check connection to mobile network configuration

If the *Check Connection* item is set to *enabled* or *enabled + bind*, checking the connection to mobile network is activated. Router will automatically send ping requests to the specified domain or IP address (*Ping IP Address* item) in regular time interval (*Ping Interval*). In case of unsuccessful ping, a new one will be sent after ten seconds. If it fails to ping the IP address of three times in a row, the router terminates the current connection and tries to establish new

ones. Checking can be set separately for two SIM cards or two APNs. As a ping address can be used an IP address for which it is certain that it is still functional and is possible to send ICMP ping (e.g. DNS server of operator).

In the case of the *enabled* option ping requests are sent on the basis of routing table. Thus, the requests may be sent through any available interface. If you require each ping request to be sent through the network interface, which was created on the occasion of establishing a connection to the mobile operator, it is necessary to set the *Check Connection* item to *enabled + bind*. The *disabled* variant deactivates checking the connection to mobile network.

Item	Description
Ping IP Address	Destinations IP address or domain name of ping queries.
Ping Interval	Time intervals between the outgoing pings.

Table 20: Check connection to mobile network configuration

If the *Enable Traffic Monitoring* option is selected, then the router stops sending ping questions to the Ping IP Address and it will watch traffic in connection to mobile network. If this connection is without traffic longer than the Ping Interval, then the router sends ping questions to the Ping IP Address.



Attention! The feature of check connection to mobile network is necessary for uninterrupted operation.

1.13.4 Data limit configuration

Item	Description
Data limit	With this parameter you can set the maximum expected amount of data transmitted (sent and received) over GPRS in one billing period (month).
Warning Threshold	Parameter <i>Warning Threshold</i> determine per cent of Data Limit in the range of 50% to 99%, which if is exceeded, then the router sends SMS in the form <i>Router has exceeded (value of Warning Threshold) of data limit</i> .
Accounting Start	Parameter sets the day of the month in which the billing cycle starts SIM card used. Start of the billing period defines the operator, which gives the SIM card. The router begin to count the transferred data since that day.

Table 21: Data limit configuration




If parameters *Switch to backup SIM card when data limit is exceeded* and *switch to default SIM card when data limit isn't exceeded* (see next subsection) or *Send SMS when datalimit is exceeded* (see SMS configuration) are not selected the data limit will not count.

1.13.5 Switch between SIM cards configuration

At the bottom of configuration it is possible to set rules for switching between two APN's on the SIM card, in the event that one SIM card is inserted or between two SIM cards, in the event that two SIM cards are inserted.

Item	Description
Default SIM card	This parameter sets default APN or SIM card, from which it will try to establish the connection to mobile network. If this parameter is set to none, the router launches in offline mode and it is necessary to establish connection to mobile network via SMS message.
Backup SIM card	Defines backup APN or SIM card, that the router will switch the defining one of the following rules.

Table 22: Default and backup SIM configuration

 If parameter Backup SIM card is set to none, then parameters *Switch to other SIM card when connection fails*, *Switch to backup SIM card when roaming is detected* and *switch to default SIM card when home network is detected* and *Switch to backup SIM card when data limit is exceeded* and *switch to default SIM card when data limit isn't exceeded* switch the router to off-line mode.

Item	Description
Switch to other SIM card when connection fails	If connection to mobile network fails, then this parameter ensures switch to secondary SIM card or secondary APN of the SIM card. Failure of the connection to mobile network can occur in two ways. When I start the router, when three fails to establish a connection to mobile network. Or if it is checked Check the connection to mobile network, and is indicated by the loss of a connection to mobile network.
Switch to backup SIM card when roaming is detected and switch to default SIM card when home network is detected	In case that the roaming is detected this parameter enables switching to secondary SIM card or secondary APN of the SIM. If home network is detected, this parameter enables switching back to default SIM card. For proper operation, it is necessary to have enabled roaming on your SIM card!
Switch to backup SIM card when data limit is exceeded and switch to default SIM card when data limit isn't exceeded	This parameter enables switching to secondary SIM card or secondary APN of the SIM card, when the data limit of default APN is exceeded. This parameter also enables switching back to default SIM card, when data limit is not exceeded.

Continued on next page

Continued from previous page

Item	Description
Switch to backup SIM card when binary input is active switch to default SIM card when binary input isn't active	This parameter enables switching to secondary SIM card or secondary APN of the SIM card, when binary input 'bin0' is active. If binary input isn't active, this parameter enables switching back to default SIM card.
Switch to default SIM card after timeout	This parameter defines the method, how the router will try to switch back to default SIM card or default APN.

Table 23: Switch between SIM card configurations

The following parameters define the time after which the router attempts to go back to the default SIM card or APN.

Item	Description
Initial timeout	The first attempt to switch back to the primary SIM card or APN shall be made for the time defined in the parameter Initial Timeout, range of this parameter is from 1 to 10000 minutes.
Subsequent Timeout	In an unsuccessful attempt to switch to default SIM card, the router on the second attempt to try for the time defined in the parameter Subsequent Timeout, range is from 1 to 10000 min.
Additive constants	Any further attempt to switch back to the primary SIM card or APN shall be made in time computed as the sum of the previous time trial and time defined in the parameter Additive constants range is 1-10000 minutes.

Table 24: Switch between SIM card configurations

Example:

If parameter *Switch to default SIM card after timeout* is checked and parameters are set as follows: *Initial Timeout* – 60 min, *Subsequent Timeout* 30 min and *Additive Timeout* – 20 min, the first attempt to switch the primary SIM card or APN shall be carried out after 60 minutes. Switched to a failed second attempt made after 30 minutes. Third after 50 minutes (30+20). Fourth after 70 minutes (30+20+20).

1.13.6 Dial-In access configuration



Dial-In access configuration is supported only for these routers: ER75i, UR5, ER75i v2 and UR5 v2.

In the bottom part of the window it is possible to define access over CSD connection by *Enable Dial-In Access* function. Access can be secured by used the *Username* and *Password*. In the event that this function is enabled and the router does not have a connection to mobile network is granted access to the router via dial-up connections CSD. The router waits 2 minutes to accept connections. If the router during this time nobody logs on, the router will try again to establish a GPRS connection.

Item	Description
Username	User name for secured Dial-In access.
Password	Password for secured Dial-In access.

Table 25: Dial-In access configuration

1.13.7 PPPoE bridge mode configuration

If the *Enable PPPoE bridge mode* option selected, it activate the PPPoE bridge protocol PPPoE (point-to-point over ethernet) is a network protocol for encapsulating Point-to-Point Protocol (PPP) frames inside Ethernet frames. Allows you to create a PPPoE connection from the device behind router. For example from PC which is connected to ETH port router. There will be allot Ip address of SIM card to PC.

The changes in settings will apply after pressing the *Apply* button.

Mobile WAN Configuration			
<input type="checkbox"/> Create connection to mobile network			
	Primary SIM card	Secondary SIM card	
APN *	<input type="text"/>	<input type="text"/>	
Username *	<input type="text"/>	<input type="text"/>	
Password *	<input type="text"/>	<input type="text"/>	
Authentication	PAP or CHAP <input type="button" value="v"/>	PAP or CHAP <input type="button" value="v"/>	
IP Address *	<input type="text"/>	<input type="text"/>	
Phone Number *	<input type="text"/>	<input type="text"/>	
Operator *	<input type="text"/>	<input type="text"/>	
PIN *	<input type="text"/>	<input type="text"/>	
MRU	1500	1500	bytes
MTU	1500	1500	bytes
DNS Settings	get from operator <input type="button" value="v"/>	get from operator <input type="button" value="v"/>	
DNS Server	<input type="text"/>	<input type="text"/>	
<i>(The feature of check connection to mobile network is necessary for uninterrupted operation)</i>			
Check Connection	disabled <input type="button" value="v"/>	disabled <input type="button" value="v"/>	
Ping IP Address	<input type="text"/>	<input type="text"/>	
Ping Interval	<input type="text"/>	<input type="text"/>	sec
<input type="checkbox"/> Enable traffic monitoring			
Data Limit	<input type="text"/>	MB	
Warning Threshold	<input type="text"/>	%	
Accounting Start	1		
Default SIM card	primary <input type="button" value="v"/>		
Backup SIM card	secondary <input type="button" value="v"/>		
<input type="checkbox"/> Switch to other SIM card when connection fails <input type="checkbox"/> Switch to backup SIM card when roaming is detected and switch to default SIM card when home network is detected <input type="checkbox"/> Switch to backup SIM card when data limit is exceeded and switch to default SIM card when data limit isn't exceeded <input type="checkbox"/> Switch to backup SIM card when binary input is active and switch to default SIM card when binary input isn't active <input type="checkbox"/> Switch to default SIM card after timeout			
Initial Timeout	60	min	
Subsequent Timeout *	<input type="text"/>	min	
Additive Constant *	<input type="text"/>	min	
<input type="checkbox"/> Enable Dial-In access			
Username *	<input type="text"/>		
Password *	<input type="text"/>		
<input type="checkbox"/> Enable PPPoE bridge mode			
* can be blank			
<input type="button" value="Apply"/>			

Figure 20: Mobile WAN configuration

The figure below describes the situation, when the connection to mobile network is controlled on the address 8.8.8.8 in the time interval of 60 s for primary SIM card and on the address www.google.com in the time interval 80 s for secondary SIM card. In the case of traffic on the router the control pings are not sent, but the traffic is monitored.

(The feature of check connection to mobile network is necessary for uninterrupted operation)

Check Connection	<input type="text" value="enabled"/>	<input type="text" value="enabled"/>
Ping IP Address	<input type="text" value="8.8.8.8"/>	<input type="text" value="www.google.com"/>
Ping Interval	<input type="text" value="60"/>	<input type="text" value="80"/> sec

☒ Enable traffic monitoring

Figure 21: Example of Mobile WAN configuration 1

The following configuration illustrates the situation in which the router switches to a backup SIM card after exceeding the data limits of 800 MB. Warning SMS is sent upon reaching 400 MB. The start of accounting period is set to the 18th day of the month.

Data Limit	<input type="text" value="800"/>	MB
Warning Threshold	<input type="text" value="50"/>	%
Accounting Start	<input type="text" value="18"/>	

Default SIM card	<input type="text" value="primary"/>
Backup SIM card	<input type="text" value="secondary"/>

☐ Switch to other SIM card when connection fails
☐ Switch to backup SIM card when roaming is detected and switch to default SIM card when home network is detected
☒ Switch to backup SIM card when data limit is exceeded and switch to default SIM card when data limit isn't exceeded
☐ Switch to backup SIM card when binary input is active and switch to default SIM card when binary input isn't active
☐ Switch to default SIM card after timeout

Initial Timeout	<input type="text" value="60"/>	min
Subsequent Timeout *	<input type="text"/>	min
Additive Constant *	<input type="text"/>	min

Figure 22: Example of Mobile WAN configuration 2

Primary SIM card is switched to the offline mode after the router detects roaming. The first attempt to switch back to the default SIM card is executed after 60 minutes, the second after 40 minutes, the third after 50 minutes (40+10) etc.

Default SIM card	<input type="text" value="primary"/>
Backup SIM card	<input type="text" value="none"/>

☐ Switch to other SIM card when connection fails
☒ Switch to backup SIM card when roaming is detected and switch to default SIM card when home network is detected
☐ Switch to backup SIM card when data limit is exceeded and switch to default SIM card when data limit isn't exceeded
☐ Switch to backup SIM card when binary input is active and switch to default SIM card when binary input isn't active
☒ Switch to default SIM card after timeout

Initial Timeout	<input type="text" value="60"/>	min
Subsequent Timeout *	<input type="text" value="40"/>	min
Additive Constant *	<input type="text" value="10"/>	min

Figure 23: Example of Mobile WAN configuration 3

1.14 PPPoE Configuration

To enter the PPPoE configuration select the *PPPoE* menu item. If the *Create PPPoE connection* option is selected, the router tries to establish PPPoE connection after switching-on. PPPoE (Point-to-Point over Ethernet) is a network protocol, which PPP frames encapsulating to the Ethernet frames. PPPoE client to connect devices that support PPPoE bridge or a server (typically ADSL router). After connecting the router obtains the IP address of the device to which it is connected. All communications from the device behind the PPPoE server is forwarded to industrial router.

Item	Description
Username	Username for secure access to PPPoE
Password	Password for secure access to PPPoE
Authentication	Authentication protocol in GSM network <ul style="list-style-type: none"> • PAP or CHAP – authentication method is chosen by router • PAP – it is used PAP authentication method • CHAP – it is used CHAP authentication method
MRU	Maximum Receiving Unit – It is the identifier of the maximum size of packet, which is possible to receive in given environment. Default value is set to 1492 bytes. Other settings may cause incorrect data transmission.
MTU	Maximum Transmission Unit – It is the identifier of the maximum size of packet, which is possible to transfer in given environment. Default value is set to 1492 bytes. Other settings may cause incorrect data transmission.

Table 26: PPPoE configuration

PPPoE Configuration

☐ Create PPPoE connection

Username *

Password *

Authentication PAP or CHAP

MRU bytes

MTU bytes

☒ Get DNS addresses from server

Figure 24: PPPoE configuration

1.15 WiFi configuration



This item is available only if the router is equipped with a WiFi module.

The form for configuration of WiFi network can be invoked by pressing the *WiFi* item in the main menu of the router web interface. *Enable WiFi* check box at the top of this form is used to activate WiFi. It is also possible to set the following properties:

Item	Description
Operating mode	<p>WiFi operating mode:</p> <ul style="list-style-type: none"> • access point (AP) – router becomes an access point to which other devices in <i>station (STA)</i> mode can be connected • station (STA) – router becomes a client station, it means that receives data packets from the available access point (AP) and sends data from cable connection via wifi network
SSID	Unique identifier of WiFi network
Broadcast SSID	<p>Method of broadcasting the unique identifier of SSID network in beacon frame and type of response to a request for sending the beacon frame.</p> <ul style="list-style-type: none"> • Enabled – SSID is broadcasted in beacon frame • Zero length – Beacon frame does not include SSID. Requests for sending beacon frame are ignored. • Clear – Each SSID character in beacon frame is replaced by 0. However, original length is kept. Requests for sending beacon frame are ignored.
Probe Hidden SSID	Probes hidden SSID (only for <i>station (STA)</i> mode)
Country Code	<p>Code of the country, where the router is used with WiFi. This code must be entered in format ISO 3166-1 alpha-2. If <i>country code</i> isn't specified and the router has implemented no system to determine this code, it is used "US" as default <i>country code</i>.</p> <p>If no <i>country code</i> is specified or is entered the wrong country code, then it may come a pass a breach of regulatory rules for the using of frequency bands in the particular country.</p>

Continued on next page

Continued from previous page

Item	Description
HW Mode	HW mode of WiFi standard that will be supported by WiFi access point (AP). <ul style="list-style-type: none"> • IEE 802.11b • IEE 802.11b+g • IEE 802.11b+g+n
Channel	Channel where the WiFi AP is transmitting
BW 40 MHz	Option for HW mode 802.11n that allows using of two standard 20 MHz channels simultaneously.
WMM	Enables basic QoS for WiFi networks. This version doesn't guarantee network throughput. It is suitable for simple applications requiring QoS.
Authentication	Provides access control of authorized users in WiFi network: <ul style="list-style-type: none"> • Open – authentication is not required (free access point) • Shared – base authentication using WEP key • WPA-PSK – authentication using better authentication method PSK-PSK • WPA2-PSK – authentication using AES encryption
Encryption	Type of data encryption in WiFi network: <ul style="list-style-type: none"> • None – No data encryption • WEP – Encryption using static WEP keys. This encryption can be used for <i>Shared</i> authentication. • TKIP – Dynamic management of encryption keys which can be used for <i>WPA-PSK</i> and <i>WPA2-PSK</i> authentication. • AES – Improved encryption used for <i>WPA2-PSK</i> authentication
WEP Key Type	Type of WEP key for WEP encryption: <ul style="list-style-type: none"> • ASCII – WEP key is entered in ASCII format • HEX – WEP key is entered in hexadecimal format
WEP Default Key	Specifies default WEP key

Continued on next page

Continued from previous page

Item	Description
WEP Key 1-4	<p>Items for different four WEP keys</p> <ul style="list-style-type: none"> • WEP key in ASCII format must be entered in quotes and must have the following lengths: <ul style="list-style-type: none"> – 5 ASCII characters (40b WEP key) – 13 ASCII characters (104b WEP key) – 16 ASCII characters (128b WEP key) • WEP key in hexadecimal format must be entered using only hexadecimal digits and must the following lengths: <ul style="list-style-type: none"> – 10 hexadecimal digits (40b WEP key) – 26 hexadecimal digits (104b WEP key) – 32 hexadecimal digits (128b WEP key)
WPA PSK Type	<p>The type of encryption when WPA-PSK authenticating:</p> <ul style="list-style-type: none"> • 256-bit secret • ASCII passphrase • PSK File
WPA PSK	<p>Key for WPA-PSK authentication. This key must be entered according to the selected WPA-PSK type as follows:</p> <ul style="list-style-type: none"> • 256-bit secret – 64 hexadecimal digits • ASCII passphrase – from 8 to 63 characters which are subsequently converted into PSK • PSK File – absolute path to the file containing the list of pairs (PSK key, MAC address)
Access List	<p>Determines a manner of Access/Deny list application:</p> <ul style="list-style-type: none"> • Disabled – Access/Deny list is not used • Accept – Only items mentioned in the Access/Deny list have access to the network • Deny – Items mentioned in the Access/Deny list do not have access to the network
Accept/Deny List	<p>Accept or Deny list of client MAC addresses that set network access. Each MAC address is separated by new line.</p>

Continued on next page

Continued from previous page

Item	Description
Syslog Level	<p>Communicativeness level when system writes to the system log</p> <ul style="list-style-type: none"> • Verbose debugging – the highest level of communicativeness • Debugging • Informational – default level of communicativeness which is used for writing standard events • Notification • Warning – the lowest level of communicativeness
Extra options	Allows user to define additional parameters

Table 27: WiFi configuration

WiFi Configuration

☐ Enable WiFi

Operating Mode

access point (AP)

SSID

Broadcast SSID

enabled

Probe Hidden SSID

☐

Country Code *

HW Mode

IEEE 802.11b

Channel

7

BW 40 MHz

☐

WMM

☐

Authentication

WPA2-PSK

Encryption

AES

WEP Key Type

ASCII

WEP Default Key

1

WEP Key 1

WEP Key 2

WEP Key 3

WEP Key 4

WPA PSK Type

256-bit secret

WPA PSK

Access List

disabled

Accept/Deny List

Syslog Level

informational

Extra options *

* can be blank

Apply

Figure 25: WiFi konfigurace

1.16 WLAN configuration



This item is available only if the router is equipped with a WiFi module.

The form for configuration of WiFi network and DHCP server functioning on this network can be invoked by pressing the *WLAN* item in the main menu of the router web interface. *Enable WLAN interface* check box at the top of this form is used to activate WiFi LAN interface. It is also possible to set the following properties:

Item	description
Operating Mode	<p>WiFi operating mode:</p> <ul style="list-style-type: none"> • access point (AP) – router becomes an access point to which other devices in <i>station (STA)</i> mode can be connected • station (STA) – router becomes a client station, it means that receives data packets from the available access point (AP) and sends data from cable connection via wifi network
DHCP Client	Activates/deactivates DHCP client
IP Address	Fixed set IP address of WiFi network interface
Subnet Mask	Subnet mask of WiFi network interface
Bridged	<p>Activates bridge mode:</p> <ul style="list-style-type: none"> • no – Bridged mode is not allowed (it's default value). WLAN network is not connected with LAN network of the router. • yes – Bridged mode is allowed. WLAN network is connected with one or more LAN network of the router. In this case, the setting of most items in this table is ignored. Instead, it takes setting of selected network interface (LAN).
Default Gateway	IP address of default gateway. When entering IP address of default gateway, all packets for which the record was not found in the routing table are sent to this address.
DNS Server	Address to which all DNS queries are forwarded

Table 28: WLAN configuration

Use *Enable dynamic DHCP leases* item at the bottom of this form to enable dynamic allocation of IP addresses using DHCP server. It is also possible to specify these values:

Item	Description
IP Pool Start	Beginning of the range of IP addresses which will be assigned to DHCP clients
IP Pool End	End of the range of IP addresses which will be assigned to DHCP clients
Lease Time	Time in seconds for which the client may use the IP address

Table 29: Configuration of DHCP server

All changes in settings will apply after pressing the *Apply* button.

WLAN Configuration

☐ Enable WLAN interface

Operating Mode

access point (AP)

DHCP Client

disabled

IP Address

Subnet Mask

Bridged

no

Default Gateway

DNS Server

☒ Enable dynamic DHCP leases

IP Pool Start

192.168.3.2

IP Pool End

192.168.3.254

Lease Time

600


sec

Figure 26: WLAN configuration

1.17 Backup Routes

Using the configuration form on the *Backup Routes* page can be set backing up primary connection by other connections to internet/mobile network. For each back up connection can be defined a priority. Own switching is done based on set priorities and state of the connection (for *Primary LAN* and *Secondary LAN*).

If *Enable backup routes switching* option is checked, the default route is selected according to the settings below. Namely according to status of enabling each of backup route (i.e. *Enable backup routes switching for Mobile WAN*, *Enable backup routes switching for PPPoE*, *Enable backup routes switching for WiFi STA*, *Enable backup routes switching for Primary LAN* or *Enable backup routes switching for Secondary LAN*), according to explicitly set priorities and according to status of connection check (if it is enabled). In addition, network interfaces belonging to individual backup routes have checked a flag *RUNNING*. This check fixes for example disconnecting of an ethernet cable.

 **Attention!** If you want to use connection to mobile WAN as one of the backup routes, it is necessary to enable *Check Connection* at *Mobile WAN* configuration to *enable + bind* option, see chapter 1.13.3.

Backup Routes Configuration	
<input type="checkbox"/>	Enable backup routes switching
<input type="checkbox"/>	Enable backup routes switching for Mobile WAN
Priority	1st
<input type="checkbox"/>	Enable backup routes switching for PPPoE
Priority	1st
Ping IP Address	
Ping Interval	sec
<input type="checkbox"/>	Enable backup routes switching for WiFi STA
Priority	1st
Ping IP Address	
Ping Interval	sec
<input type="checkbox"/>	Enable backup routes switching for Primary LAN
Priority	1st
Ping IP Address	
Ping Interval	sec
<input type="checkbox"/>	Enable backup routes switching for Secondary LAN
Priority	1st
Ping IP Address	
Ping Interval	sec
<input type="button" value="Apply"/>	

Figure 27: Backup Routes

If *Enable backup routes switching* option is not checked, Backup routes system operates in the so-called backward compatibility mode. The default route is selected based on implicit priorities according to the status of enabling settings for each of network interface, as the case may be enabling services that set these network interfaces. Names of backup routes and corresponding network interfaces in order of implicit priorities:

- Mobile WAN (pppX, usbX)
- PPPoE (ppp0)
- Secondary LAN (eth1)
- Primary LAN (eth0)

Example:

Secondary LAN is selected as the default route only if *Create connection to mobile network* option is not checked on the *Mobile WAN* page, alternatively if *Create PPPoE connection* option is not checked on the *PPPoE* page. To select the Primary LAN it is also necessary not to be entered *IP address* for Secondary LAN and must not be enabled *DHCP Client* for Secondary LAN.

Item	Description
Priority	Priority for the type of connection
Ping IP Address	Destination IP address of ping queries to check the connection (address can not be specified as a domain name)
Ping Interval	The time intervals between sent ping queries

Table 30: Backup Routes

All changes in settings will be applied after pressing the *Apply* button.

1.18 Firewall configuration

The first security element which incoming packets must pass is check of enabled source IP addresses and destination ports. It can be specified IP addresses from which you can remotely access the router and the internal network connected behind a router. If the *Enable filtering of incoming packets* item is checked (located at the beginning of the configuration form *Firewall*), this element is enabled and accessibility is checked against the table with IP addresses. This means that access is permitted only addresses specified in the table. It is possible to define up to eight remote accesses. There are the following parameters:

Item	Description
Source	IP address from which access to the router is allowed
Protocol	Specifies protocol for remote access: <ul style="list-style-type: none"> • all – access is enabled for all protocols • TCP – access is enabled for TCP protocol • UDP – access is enabled for UDP protocol • ICMP – access is enabled for ICMP protocol
Target Port	The port number on which access to the router is allowed
Action	Type of action: <ul style="list-style-type: none"> • allow – access is allowed • deny – access is denied

Table 31: Filtering of incoming packets

The following part of the configuration form defines the forwarding policy. If *Enabled filtering of forwarded packets* item is not checked, packets are automatically accepted. If this item is checked and incoming packet is addressed to another network interface, it will go to the FORWARD chain. In case that the FORWARD chain accepted this packet (there is a rule for its forwarding), it will be sent out. If the forwarding rule does not exist, packet will be dropped.

Then there is a table for defining the rules. It is possible to allow all traffic within the selected protocol (rule specifies only protocol) or create stricter rules by specifying items for source IP address, destination IP address and port.

Item	Description
Source	IP address of source device
Destination	IP address of destination device
Protocol	Specifies protocol for remote access: <ul style="list-style-type: none"> • all – access is enabled for all protocols • TCP – access is enabled for TCP protocol • UDP – access is enabled for UDP protocol • ICMP – access is enabled for ICMP protocol
Target Port	The port number on which access to the router is allowed

Continued on next page

Continued from previous page

Item	Description
Action	<p>Type of action:</p> <ul style="list-style-type: none"> • allow – access is allowed • deny – access is denied

Table 32: Forwarding filtering

There is also the possibility to drop a packet whenever request for service which is not in the router comes (check box named *Enable filtering of locally destined packets*). The packet is dropped automatically without any information.

As a protection against DoS attacks (this means attacks during which the target system is flooded with plenty of meaningless requirements) is used option named *Enable protection against DoS attacks* which limits the number of connections per second for five.

Firewall Configuration

☐ Enable filtering of incoming packets

Source *	Protocol	Target Port *	Action
<input type="checkbox"/>	all ▼		allow ▼
<input type="checkbox"/>	all ▼		allow ▼
<input type="checkbox"/>	all ▼		allow ▼
<input type="checkbox"/>	all ▼		allow ▼
<input type="checkbox"/>	all ▼		allow ▼
<input type="checkbox"/>	all ▼		allow ▼
<input type="checkbox"/>	all ▼		allow ▼
<input type="checkbox"/>	all ▼		allow ▼
<input type="checkbox"/>	all ▼		allow ▼

☐ Enabled filtering of forwarded packets

Source *	Destination *	Protocol	Target Port *	Action
<input type="checkbox"/>		all ▼		allow ▼
<input type="checkbox"/>		all ▼		allow ▼
<input type="checkbox"/>		all ▼		allow ▼
<input type="checkbox"/>		all ▼		allow ▼
<input type="checkbox"/>		all ▼		allow ▼
<input type="checkbox"/>		all ▼		allow ▼
<input type="checkbox"/>		all ▼		allow ▼
<input type="checkbox"/>		all ▼		allow ▼
<input type="checkbox"/>		all ▼		allow ▼

☐ Enable filtering of locally destined packets

☐ Enable protection against DoS attacks

* can be blank

Figure 28: Firewall configuration

Example of the firewall configuration:

The router has allowed the following access:

- from address 171.92.5.45 using any protocol
- from address 10.0.2.123 using TCP protocol on port 1000
- from address 142.2.26.54 using ICMP protocol




Figure 29: Topology of example firewall configuration

Firewall Configuration			
<input checked="" type="checkbox"/> Enable filtering of incoming packets			
Source *	Protocol	Target Port *	Action
<input checked="" type="checkbox"/> 171.92.5.45	all		allow
<input checked="" type="checkbox"/> 10.0.2.123	TCP	1000	allow
<input checked="" type="checkbox"/> 142.2.26.54	ICMP		allow
<input type="checkbox"/>	all		allow
<input type="checkbox"/>	all		allow
<input type="checkbox"/>	all		allow
<input type="checkbox"/>	all		allow
<input type="checkbox"/>	all		allow

Figure 30: Example firewall configuration

1.19 NAT configuration

To enter the Network Address Translation configuration, select the *NAT* menu item. NAT (Network address Translation / Port address Translation - PAT) is a method of adjusting the network traffic through the router default transcript and/or destination IP addresses often change the number of TCP/UDP port for walk-through IP packets. The window contains sixteen entries for the definition of NAT rules.

Item	Description
Public Port	Public port
Private Port	Private port
Type	Protocol selection
Server IP address	IP address which will be forwarded incoming data

Table 33: NAT configuration

If necessary set more than sixteen rules for NAT rules, then is possible insert into start up script following script:

```
iptables -t nat -A napt -p tcp --dport [PORT\_PUBLIC] -j DNAT --to-destination [IPADDR] : [PORT1\_PRIVATE]
```

Concrete IP address [IPADDR] and ports numbers [PORT_PUBLIC] and [PORT_PRIVATE] are filled up into square bracket.

The following items are used to set the routing of all incoming traffic from the PPP to the connected computer.

Item	Description
Send all remaining incoming packets to default server	By checking this item and setting the Default Server item it is possible to put the router into the mode in which all incoming data from GPRS will be routed to the computer with the defined IP address.
Default Server IP Address	Send all incoming packets to this IP addresses.

Table 34: Configuration of send all incoming packets

Enable the following options and enter the port number is allowed remote access to the router from PPP interface.

Item	Description
Enable remote HTTP access on port	If this item field and port number is filled in, then configuration of the router over web interface is possible (disabled in default configuration).
Enable remote HTTPS access on port	If this item field and port number is filled in, then configuration of the router over web interface is possible (disabled in default configuration).
Enable remote FTP access on port	Choice this item and port number makes it possible to access over FTP (disabled in default configuration).
Enable remote SSH access on port	Choice this item and port number makes it possible to access over SSH (disabled in default configuration).
Enable remote Telnet access on port	Choice this item and port number makes it possible to access over Telnet (disabled in default configuration).
Enable remote SNMP access on port	Choice this item and port number makes it possible to access to SNMP agent (disabled in default configuration).
Masquerade outgoing packets	Choice Masquerade (alternative name for the NAT system) item option turns the system address translation NAT.

Table 35: Remote access configuration

Example of the configuration with one connection equipment on the router:




Figure 31: Topology of example NAT configuration 1

NAT Configuration			
Public Port	Private Port	Type	Server IP Address
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	

☒ Enable remote HTTP access on port
☐ Enable remote HTTPS access on port
☒ Enable remote FTP access on port
☐ Enable remote SSH access on port
☒ Enable remote Telnet access on port
☒ Enable remote SNMP access on port

☒ Send all remaining incoming packets to default server
 Default Server IP Address

☒ Masquerade outgoing packets

Figure 32: Example NAT configuration 1

In these configurations it is important to have marked choice of *Send all remaining incoming packets to default server*, IP address in this case is the address of the device behind the router. Connected equipment behind the router must have set *Default Gateway* on the router. Connected device replies, while PING on IP address of SIM card.

Example of the configuration with more connected equipment:




Figure 33: Topology of example NAT configuration 2

NAT Configuration			
Public Port	Private Port	Type	Server IP Address
81	80	TCP ▼	198.162.1.2
82	80	TCP ▼	198.162.1.3
83	80	TCP ▼	198.162.1.4
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	
		TCP ▼	

☒ Enable remote HTTP access on port
☐ Enable remote HTTPS access on port
☒ Enable remote FTP access on port
☐ Enable remote SSH access on port
☒ Enable remote Telnet access on port
☒ Enable remote SNMP access on port

☐ Send all remaining incoming packets to default server
 Default Server IP Address:

☒ Masquerade outgoing packets

Figure 34: Example NAT configuration 2

In this example there is more equipment connected behind the router, using a Switch. Every device connected behind the router has its own IP address and this is the address to fill in the *Server IP Address* field in the NAT configuration. These devices are all communicating on the port 80, but you can set the Port Forwarding in the NAT configuration – see Figure 31 – *Public Port* and *Private Port* fields. It is now configured to access 192.168.1.2:80 socket behind the router when accessing 10.0.0.1:81 from the Internet and so on. If you send the ping request to the public IP address of the router (10.0.0.1), the router will respond as usual (not forwarding). If you access the IP address 10.0.0.1 in the browser (it is port 80), the router's Web interface will come up since *Enable remote HTTP access on port 80* is checked.

1.20 OpenVPN tunnel configuration

OpenVPN tunnel configuration can be called up by option *OpenVPN* item in the menu. OpenVPN tunnel allows protected connection of two networks LAN to the one which looks like one homogenous. In the *OpenVPN Tunnels Configuration* window are two rows, each row for one configured OpenVPN tunnel.

Item	Description
Create	Enables the individual tunnels
Description	Displays a name of the tunnel specified in the configuration form
Edit	Configuration of OpenVPN tunnel

Table 36: Overview OpenVPN tunnels

Figure 35: OpenVPN tunnels configuration

Item	Description
Description	Description (or name) of tunnel
Protocol	Communication protocol: <ul style="list-style-type: none"> • UDP – OpenVPN will communicate using UDP • TCP server – OpenVPN will communicate using TCP in server mode • TCP client – OpenVPN will communicate using TCP in client mode

Continued on next page

Continued from previous page

Item	Description
UDP/TCP port	Port of the relevant protocol (UDP or TCP)
Remote IP Address	IP address of opposite tunnel side (domain name can be used)
Remote Subnet	IP address of a network behind opposite tunnel side
Remote Subnet Mask	Subnet mask of a network behind opposite tunnel side
Redirect Gateway	Allows to redirect all traffic on Ethernet
Local Interface IP Address	Defines the IP address of a local interface
Remote Interface IP Address	Defines the IP address of the interface of opposite tunnel side
Ping Interval	Defines the time interval after which sends a message to opposite side of tunnel for checking the existence of the tunnel.
Ping Timeout	Defines the time interval during which the router waits for a message sent by the opposite side. For proper verification of OpenVPN tunnel, <i>Ping Timeout</i> must be greater than <i>Ping Interval</i> .
Renegotiate Interval	Sets renegotiate period (reauthorization) of the OpenVPN tunnel. This parameter can be set only when <i>Authenticate Mode</i> is set to <i>username/password</i> or <i>X.509 certificate</i> . After this time period, router changes the tunnel encryption to ensure the continues safety of the tunnel.
Max Fragment Size	Defines the maximum size of a sent packet
Compression	Sent data can be compressed: <ul style="list-style-type: none"> • none – no compression is used • LZO – a lossless compression is used (must be set on both sides of the tunnel!)
NAT Rules	Applies NAT rules to the OpenVPN tunnel: <ul style="list-style-type: none"> • not applied – NAT rules are not applied to the OpenVPN tunnel • applied – NAT rules are applied to the OpenVPN tunnel

Continued on next page

Continued from previous page

Item	Description
Authenticate Mode	<p>Sets authentication mode:</p> <ul style="list-style-type: none"> • none – no authentication is set • Pre-shared secret – sets the shared key for both sides of the tunnel • Username/password – enables authentication using <i>CA Certificate</i>, <i>Username</i> and <i>Password</i> • X.509 Certificate (multiclient) – enables X.509 authentication in multiclient mode • X.509 Certificate (client) – enables X.509 authentication in client mode • X.509 Certificate (server) – enables X.509 authentication in server mode
Pre-shared Secret	Authentication using pre-shared secret can be used for all offered authentication mode.
CA Certificate	Auth. using CA Certificate can be used for username/password and X.509 Certificate modes.
DH Parameters	Protocol for exchange key DH parameters can be used for X.509 Certificate authentication in server mode.
Local Certificate	This authentication certificate can be used for X.509 Certificate authentication mode.
Local Private Key	It can be used for X.509 Certificate authentication mode.
Username	Authentication using a login name and password authentication can be used for username/password mode.
Password	Authentication using a login name and password authentication can be used for username/password mode.
Extra Options	Allows to define additional parameters of OpenVPN tunnel such as DHCP options etc. Parameters are introduced by two dashes. For possible parameters see the help in the router via SSH – run the <code>openvpnd --help</code> command.

Table 37: OpenVPN tunnels configuration

The changes in settings will apply after pressing the *Apply* button.

OpenVPN Tunnel Configuration

☐ Create 1st OpenVPN tunnel

Description *

Protocol

UDP port

Remote IP Address *

Remote Subnet *

Remote Subnet Mask *

Redirect Gateway

Local Interface IP Address

Remote Interface IP Address

Ping Interval *

sec

Ping Timeout *

sec

Renegotiate Interval *

sec

Max Fragment Size *

bytes

Compression

NAT Rules

Authenticate Mode

Pre-shared Secret

CA Certificate

DH Parameters

Local Certificate

Local Private Key

Username

Password

Extra Options *

* can be blank

Figure 36: OpenVPN tunnel configuration

Example of the OpenVPN tunnel configuration:




Figure 37: Topology of example OpenVPN configuration

OpenVPN tunnel configuration:

Configuration	A	B
Protocol	UDP	UDP
UDP Port	1194	1194
Remote IP Address	10.0.0.2	10.0.0.1
Remote Subnet	192.168.2.0	192.168.1.0
Remote Subnet Mask	255.255.255.0	255.255.255.0
Local Interface IP Address	19.16.1.0	19.16.2.0
Remote Interface IP Address	19.16.2.0	19.18.1.0
Compression	LZO	LZO
Authenticate mode	none	none

Table 38: Example OpenVPN configuration

Examples of different options for configuration and authentication of OpenVPN tunnel can be found in the application note *OpenVPN*.

1.21 IPsec tunnel configuration

IPsec tunnel configuration can be called up by option *IPsec* item in the menu. IPsec tunnel allows protected (encrypted) connection of two networks LAN to the one which looks like one homogenous. In the *IPsec Tunnels Configuration* window are four rows, each row for one configured one IPsec tunnel.

Item	Description
Create	This item enables the individual tunnels.
Description	This item displays the name of the tunnel specified in the configuration of the tunnel.
Edit	Configuration IPsec tunnel.

Table 39: Overview IPsec tunnels

Figure 38: IPsec tunnels configuration

Item	Description
Description	Name (description) of the tunnel
Remote IP Address	IP address of remote side of the tunnel. It is also possible to enter the domain name.
Remote ID	Identifier (ID) of remote side of the tunnel. It consists of two parts: <i>hostname</i> and <i>domain-name</i> (more information can be found under the table).
Remote Subnet	IP address of a network behind remote side of the tunnel
Remote Subnet Mask	Subnet mask of a network behind remote side of the tunnel
Remote Protocol/Port	Specifies Protocol/Port of remote side of the tunnel. The general form is <i>protocol/port</i> , for example 17/1701 for UDP (protocol 17) and port 1701. It is also possible to enter only the number of protocol, however, the above mentioned format is preferred.

Continued on next page

Continued from previous page

Item	Description
Local ID	Identifier (ID) of local side of the tunnel. It consists of two parts: <i>hostname</i> and <i>domain-name</i> (more information can be found under the table).
Local Subnet	IP address of a local network
Local Subnet Mask	Subnet mask of a local network
Local Protocol/Port	Specifies Protocol/Port of a local network. The general form is <i>protocol/port</i> , for example 17/1701 for UDP (protocol 17) and port 1701. It is also possible to enter only the number of protocol, however, the above mentioned format is preferred.
Encapsulation Mode	IPsec mode (according to the method of encapsulation) – You can choose <i>tunnel</i> (entire IP datagram is encapsulated) or <i>transport</i> (only IP header).
NAT traversal	If address translation is used between two end points of the tunnel, it needs to enable <i>NAT Traversal</i> .
IKE Mode	Defines mode for establishing connection (<i>main</i> or <i>aggressive</i>). If the aggressive mode is selected, establishing of IPsec tunnel will be faster, but encryption will set permanently on 3DES-MD5. We recommend not to use <i>aggressive</i> mode due to a lower security!
IKE Algorithm	Way of algorithm selection: <ul style="list-style-type: none"> • auto – encryption and hash alg. are selected automatically • manual – encryption and hash alg. are defined by the user
IKE Encryption	Encryption algorithm – 3DES, AES128, AES192, AES256
IKE Hash	Hash algorithm – MD5, SHA1, SHA256, SHA384 or SHA512
IKE DH Group	Diffie-Hellman groups determine the strength of the key used in the key exchange process. Higher group numbers are more secure, but require additional time to compute the key. Group with higher number provides more security, but requires more processing time.
ESP Algorithm	Way of algorithm selection: <ul style="list-style-type: none"> • auto – encryption and hash alg. are selected automatically • manual – encryption and hash alg. are defined by the user
ESP Encryption	Encryption algorithm – DES, 3DES, AES128, AES192, AES256

Continued on next page

Continued from previous page

Item	Description
ESP Hash	Hash algorithm – MD5, SHA1, SHA256, SHA384 or SHA512
PFS	Ensures that derived session keys are not compromised if one of the private keys is compromised in the future
PFS DH Group	Diffie-Hellman group number (see <i>IKE DH Group</i>)
Key Lifetime	Lifetime key data part of tunnel. The minimum value of this parameter is 60 s. The maximum value is 86400 s.
IKE Lifetime	Lifetime key service part of tunnel. The minimum value of this parameter is 60 s. The maximum value is 86400 s.
Rekey Margin	Specifies how long before connection expiry should attempt to negotiate a replacement begin. Maximum value must be less than half of IKE and Key Lifetime parameters.
Rekey Fuzz	Percentage extension of Rekey Margin time
DPD Delay	Time after which the IPsec tunnel functionality is tested
DPD Timeout	The period during which device waits for a response
Authenticate Mode	Using this parameter can be set authentication: <ul style="list-style-type: none"> • Pre-shared key – sets the shared key for both sides of the tunnel • X.509 Certificate – allows X.509 authentication in multi-client mode
Pre-shared Key	Shared key for both sides of the tunnel to Pre-shared key authenticate
CA Certificate	Certificate for X.509 authentication
Remote Certificate	Certificate for X.509 authentication
Local Certificate	Certificate for X.509 authentication
Local Private Key	Private key for X.509 authentication
Local Passphrase	Passphrase for X.509 authentication
Extra Options	Use this parameter to define additional parameters of the IPsec tunnel, for example secure parameters etc.

Table 40: IPsec tunnel configuration

IPsec supports the following types of identifiers (ID) of both tunnel sides (*Remote ID* and *Local ID* items):

- IP address (e.g. 192.168.1.1)
- DN (e.g. C=CZ,O=Conel,OU=TP,CN=A)
- FQDN (e.g. @director.conel.cz) – **in front of FQDN must always be @**
- User FQDN (e.g. director@conel.cz)



The certificates and private keys have to be in PEM format. As certificate it is possible to use only certificate which has start and stop tag certificate.



Random time, after which it will re-exchange of new keys are defined:

*Lifetime - (Rekey margin + random value in range (from 0 to Rekey margin * Rekey Fuzz/100))*

By default, the repeated exchange of keys held in the time range:

- Minimal time: 1h - (9m + 9m) = 42m
- Maximal time: 1h - (9m + 0m) = 51m

When setting the times for key exchange is recommended to leave the default setting in which tunnel has guaranteed security. When set higher time, tunnel has smaller operating costs and smaller the safety. Conversely, reducing the time, tunnel has higher operating costs and higher safety of the tunnel.

The changes in settings will apply after pressing the *Apply* button.

IPsec Tunnel Configuration	
<input type="checkbox"/> Create 1st IPsec tunnel	
Description *	<input type="text"/>
Remote IP Address *	<input type="text"/>
Remote ID *	<input type="text"/>
Remote Subnet *	<input type="text"/>
Remote Subnet Mask *	<input type="text"/>
Remote Protocol/Port *	<input type="text"/>
Local ID *	<input type="text"/>
Local Subnet *	<input type="text"/>
Local Subnet Mask *	<input type="text"/>
Local Protocol/Port *	<input type="text"/>
Encapsulation Mode	tunnel ▼
NAT Traversal	disabled ▼
IKE Mode	main ▼
IKE Algorithm	auto ▼
IKE Encryption	3DES ▼
IKE Hash	MD5 ▼
IKE DH Group	2 ▼
ESP Algorithm	auto ▼
ESP Encryption	DES ▼
ESP Hash	MD5 ▼
PFS	disabled ▼
PFS DH Group	2 ▼
Key Lifetime	3600 sec
IKE Lifetime	3600 sec
Rekey Margin	540 sec
Rekey Fuzz	100 %
DPD Delay *	sec
DPD Timeout *	sec
Authenticate Mode	pre-shared key ▼
Pre-shared Key	<input type="text"/>
CA Certificate	<input type="text"/>
Remote Certificate	<input type="text"/>
Local Certificate	<input type="text"/>
Local Private Key	<input type="text"/>
Local Passphrase *	<input type="text"/>
Extra Options *	<input type="text"/>
* can be blank	
<input type="button" value="Apply"/>	

Figure 39: IPsec tunnels configuration

Example of the IPsec Tunnel configuration:





Figure 40: Topology of example IPsec configuration


IPsec tunnel configuration:

Configuration	A	B
Remote IP Address	10.0.0.2	10.0.0.1
Remote Subnet	192.168.2.0	192.168.1.0
Remote Subnet Mask	255.255.255.0	255.255.255.0
Local Subnet	192.168.1.0	192.168.2.0
Local Subnet Mas:	255.255.255.0	255.255.255.0
Authenticate mode	pre-shared key	pre-shared key
Pre-shared key	test	test

Table 41: Example IPsec configuration

 Examples of different options for configuration and authentication of IPsec tunnel can be found in the application note *IPsec*.

1.22 GRE tunnels configuration

 GRE is an unencrypted protocol.

To enter the GRE tunnels configuration, select the *GRE* menu item. The GRE tunnel is used for connection of two networks to one that appears as one homogenous. It is possible to configure up to four GRE tunnels. In the *GRE Tunnels Configuration* window are four rows, each row for one configured GRE tunnel.

Item	Description
Create	Enables the individual tunnels
Description	Displays the name of the tunnel specified in the configuration form
Edit	Configuration of GRE tunnel

Table 42: Overview GRE tunnels

Figure 41: GRE tunnels configuration

Item	Description
Description	Description of tunnel.
Remote IP Address	IP address of the remote side of the tunnel
Local Interface IP Address	IP address of the local side of the tunnel
Remote Interface IP Address	IP address of the remote side of the tunnel
Remote Subnet	IP address of the network behind the remote side of the tunnel
Remote Subnet Mask	Mask of the network behind the remote side of the tunnel
Multicasts	Enables/disables multicast: <ul style="list-style-type: none"> • disabled – multicast disabled • enabled – multicast enabled
Pre-shared Key	An optional value that defines the 32 bit shared key in numeric format, through which the filtered data through the tunnel. This key must be defined on both routers as same, otherwise the router will drop received packets. Using this key, the data do not provide a tunnel through.

Table 43: GRE tunnel configuration



Attention, GRE tunnel doesn't connect itself via NAT.

The changes in settings will apply after pressing the *Apply* button.

GRE Tunnel Configuration

☐ Create 1st GRE tunnel

Description *

Remote IP Address

Remote Subnet *

Remote Subnet Mask *

Local Interface IP Address *

Remote Interface IP Address *

Multicasts ▼

Pre-shared Key *

* can be blank

Figure 42: GRE tunnel configuration

Example of the GRE Tunnel configuration:




Figure 43: Topology of GRE tunnel configuration

GRE tunnel Configuration:

Configuration	A	B
Remote IP Address	10.0.0.2	10.0.0.1
Remote Subnet	192.168.2.0	192.168.1.0
Remote Subnet Mask	255.255.255.0	255.255.255.0

Table 44: Example GRE tunnel configuration

Examples of different options for configuration of GRE tunnel can be found in the application note *GRE Tunnel*.

1.23 L2TP tunnel configuration



L2TP is an unencrypted protocol.

To enter the L2TP tunnels configuration, select the L2TP menu item. L2TP tunnel allows protected connection by password of two networks LAN to the one which it looks like one homogenous. The tunnels are active after selecting Create L2TP tunnel.

Item	Description
Mode	L2TP tunnel mode on the router side: <ul style="list-style-type: none"> • L2TP server – in the case of a server must be defined IP address range offered by the server • L2TP client – in case of client must be defined the IP address of the server
Server IP Address	IP address of server
Client Start IP Address	Start IP address in range, which is offered by server to clients
Client End IP Address	End IP address in range, which is offered by server to clients
Local IP Address	IP address of the local side of the tunnel
Remote IP Address	IP address of the remote side of the tunnel
Remote Subnet	Address of the network behind the remote side of the tunnel
Remote Subnet Mask	The mask of the network behind the remote side of the tunnel
Username	Username for login to L2TP tunnel
Password	Password for login to L2TP tunnel

Table 45: L2TP tunnel configuration

The changes in settings will apply after pressing the *Apply* button.

L2TP Tunnel Configuration

☐ Create L2TP tunnel

Mode

L2TP client

Server IP Address

Client Start IP Address

Client End IP Address

Local IP Address *

Remote IP Address *

Remote Subnet *

Remote Subnet Mask *

Username

Password

* can be blank

Figure 44: L2TP tunnel configuration

Example of the L2TP Tunnel configuration:




Figure 45: Topology of example L2TP tunnel configuration

Configuration of the L2TP tunnel:

Configuration	A	B
Mode	L2TP Server	L2TP Client
Server IP Address	—	10.0.0.1
Client Start IP Address	192.168.1.2	—
Client End IP Address	192.168.1.254	—
Local IP Address	192.168.1.1	—
Remote IP Address	—	—
Remote Subnet	192.168.2.0	192.168.1.0
Remote Subnet Mask	255.255.255.0	255.255.255.0
Username	username	username
Password	password	password

Table 46: Example L2TP tunnel configuration

1.24 PPTP tunnel configuration



PPTP is an unencrypted protocol.

To enter the PPTP tunnels configuration, select the *PPTP* menu item. PPTP tunnel allows protected connection by password of two networks LAN to the one which it looks like one homogenous. It is a similar method of VPN execution as L2TP. The tunnels are active after selecting *Create PPTP tunnel*.

Item	Description
Mode	PPTP tunnel mode on the router side: <ul style="list-style-type: none"> • PPTP server – in the case of a server must be defined IP address range offered by the server • PPTP client – in case of client must be defined the IP address of the server
Server IP Address	IP address of server
Local IP Address	IP address of the local side of the tunnel
Remote IP Address	IP address of the remote side of the tunnel
Remote Subnet	Address of the network behind the remote side of the tunnel
Remote Subnet Mask	The mask of the network behind the remote side of the tunnel
Username	Username for login to PPTP tunnel
Password	Password for login to PPTP tunnel

Table 47: PPTP tunnel configuration

The changes in settings will apply after pressing the *Apply* button.

Figure 46: PPTP tunnel configuration



Since firmware 3.0.9 is added support for PPTP passthrough, which means that it is possible to create a tunnel through router.

Example of the PPTP Tunnel configuration:




Figure 47: Topology of example PPTP tunnel configuration

Configuration of the PPTP tunnel:

Configuration	A	B
Mode	PPTP Server	PPTP Client
Server IP Address	—	10.0.0.1
Local IP Address	192.168.1.1	—
Remote IP Address	—	—
Remote Subnet	192.168.2.0	192.168.1.0
Remote Subnet Mask	255.255.255.0	255.255.255.0
Username	username	username
Password	password	password

Table 48: Example PPTP tunnel configuration

1.25 DynDNS client configuration

With the DynDNS service you can access the router remotely using an easy to remember custom hostname. This client monitors the router's IP address and update it whenever it changes. To make DynDNS work it is necessary to have a public IP address (static or dynamic) and an active account at www.dyndns.org (Remote Access service).

DynDNS client Configuration is accessible in the *DynDNS* item in the menu. There has to be registered custom domain (third-level) and account information defined in the configuration form.

Item	Description
Hostname	Third order domain registered on server www.dyndns.org
Username	Username for login to DynDNS server
Password	Password for login to DynDNS server
Server	If you want to use another DynDNS service than www.dyndns.org , then enter the update server service to this item. If this item is left blank, it uses the default server members.dyndns.org .

Table 49: DynDNS configuration

Example of the DynDNS client configuration with domain conel.dyndns.org:

DynDNS Configuration

☒ Enable DynDNS client

Hostname

Username

Password

Server *

* can be blank

Figure 48: Example of DynDNS configuration

1.26 NTP client configuration

NTP client Configuration can be called up by option *NTP* item in the menu. NTP (Network Time Protocol) allows set the exact time to the router from the servers, which provide the exact time on the network.

By parameter *Enable local NTP service* router is set to a mode in which it operates as an NTP server for other devices in the LAN behind the router.

By parameter *Enable local NTP service* it is possible to set the router in mode, that it can serve as NTP server for other devices.

Item	Description
Primary NTP Server Address	IP or domain address primary NTP server.
Secondary NTP Server Address	IP or domain address secondary NTP server.
Timezone	By this parameter it is possible to set the time zone of the router
Daylight Saving Time	Using this parameter can be defined time shift: <ul style="list-style-type: none"> • No – time shift is disabled • Yes – time shift is allowed

Table 50: NTP configuration

Example of the NTP conf. with set primary (ntp.cesnet.cz) and secondary (tik.cesnet.cz) NTP server and with daylight saving time:

NTP Configuration

☐ Enable local NTP service

☒ Synchronize clock with NTP server

Primary NTP Server:

Secondary NTP Server:

Timezone:

Daylight Saving Time:

Figure 49: Example of NTP configuration

1.27 SNMP configuration


To enter the *SNMP configuration* it is possible with SNMP agent v1/v2 or v3 configuration which sends information about the router, eventually about the status of the expansion port CNT or MBUS.

SNMP (Simple Network Management Protocol) provides status information about network elements such as routers or end computers.

Item	Description
Name	Designation of the router.
Location	Placing of the router.
Contact	Person who manages the router together with information how to contact this person.

Table 51: SNMP agent configuration

Enabling SNMPv1/v2 is performed using the *Enable SNMPv1/v2 access* item. It is also necessary to define a password for access to the SNMP agent (*Community*). Standardly is used *public* that is predefined.

 At SNMPv1/v2 it is possible to define a different password for *Read* community (read only) and *Write* community (read and write). At SNMPv3 you can define two SNMP users. One can read only (*Read*), the second can read and write (*Write*). The items in the following table can be set up for every user separately. These are not router's Web interface users, just the SNMP access users.

The *Enable SNMPv3 access* item allows you to enable SNMPv3. Then you must define the following parameters:

Item	Description
Username	User name
Authentication	Encryption algorithm on the Authentication Protocol that is used to ensure the identity of users.
Authentication Password	Password used to generate the key used for authentication.
Privacy	Encryption algorithm on the Privacy Protocol that is used to ensure confidentiality of data.
Privacy Password	Password for encryption on the Privacy Protocol.


Table 52: SNMPv3 configuration

In addition, you can continue with this configuration:

- By choosing *Enable I/O extension* it is possible to monitor binary inputs I/O on the router.
- By choosing *Enable XC-CNT extension* it is possible to monitor the expansion port CNT inputs and outputs status.
- By choosing *Enable M-BUS extension* and enter the *Baudrate*, *Parity* and *Stop Bits* it is possible to monitor the meter status connected to the expansion port MBUS status.

Item	Description
Baudrate	Communication speed.
Parity	Control parity bit: <ul style="list-style-type: none"> • none – data will be sent without parity • even – data will be sent with even parity • odd – data will be sent with odd parity
Stop Bits	Number of stop bit.

Table 53: SNMP configuration (MBUS extension)

 Parameters *Enable XC-CNT extension* and *Enable M-BUS extension* can not be checked together.

By choosing *Enable reporting to supervisory system* and enter the *IP Address* and *Period* it is possible to send statistical information to the monitoring system R-SeeNet.

Item	Description
IP Address	IP address
Period	Period of sending statistical information (in minutes)

Table 54: SNMP configuration (R-SeeNet)

Every monitor value is uniquely identified by the help of number identifier *OID* – *Object Identifier*. For binary input and output the following range of OID is used:

OID	Description
.1.3.6.1.4.1.30140.2.3.1.0	Binary input BIN0 (values 0,1)
.1.3.6.1.4.1.30140.2.3.2.0	Binary output OUT0 (values 0,1)

Table 55: Object identifier for binary input and output

For the expansion port CNT the following range of OID is used:

OID	Description
.1.3.6.1.4.1.30140.2.1.1.0	Analogy input AN1 (range 0-4095)
.1.3.6.1.4.1.30140.2.1.2.0	Analogy input AN2 (range 0-4095)
.1.3.6.1.4.1.30140.2.1.3.0	Counter input CNT1 (range 0-4294967295)
.1.3.6.1.4.1.30140.2.1.4.0	Counter input CNT2 (range 0-4294967295)
.1.3.6.1.4.1.30140.2.1.5.0	Binary input BIN1 (values 0,1)
.1.3.6.1.4.1.30140.2.1.6.0	Binary input BIN2 (values 0,1)
.1.3.6.1.4.1.30140.2.1.7.0	Binary input BIN3 (values 0,1)
.1.3.6.1.4.1.30140.2.1.8.0	Binary input BIN4 (values 0,1)
.1.3.6.1.4.1.30140.2.1.9.0	Binary output OUT1 (values 0,1)

Table 56: Object identifier for CNT port

For the expansion port M-BUS the following range of OID is used:

OID	Description
.1.3.6.1.4.1.30140.2.2.<address>.1.0	IdNumber – meter number
.1.3.6.1.4.1.30140.2.2.<address>.2.0	Manufacturer
.1.3.6.1.4.1.30140.2.2.<address>.3.0	Version – specified meter version
.1.3.6.1.4.1.30140.2.2.<address>.4.0	Medium – type of metered medium
.1.3.6.1.4.1.30140.2.2.<address>.5.0	Status – errors report
.1.3.6.1.4.1.30140.2.2.<address>.6.0	0. VIF – value information field
.1.3.6.1.4.1.30140.2.2.<address>.7.0	0. measured value
.1.3.6.1.4.1.30140.2.2.<address>.8.0	1. VIF – value information field
.1.3.6.1.4.1.30140.2.2.<address>.9.0	1. measured value
.1.3.6.1.4.1.30140.2.2.<address>.10.0	2. VIF – value information field
.1.3.6.1.4.1.30140.2.2.<address>.11.0	2. measured value
.1.3.6.1.4.1.30140.2.2.<address>.12.0	3. VIF – value information field
.1.3.6.1.4.1.30140.2.2.<address>.13.0	3. measured value
⋮	⋮
.1.3.6.1.4.1.30140.2.2.<address>.100.0	47. VIF – value information field
.1.3.6.1.4.1.30140.2.2.<address>.101.0	47. measured value

Table 57: Object identifier for M-BUS port

The meter address can be from range 0..254 when 254 is broadcast.

Since firmware 3.0.4 all v2 routers with board RB-v2-6 and newer provide information about internal temperature of device (OID 1.3.6.1.4.1.30140.3.3) and power voltage (OID 1.3.6.1.4.1.30140.3.4).

Example of SNMP settings and readout:

SNMP Configuration	
<input checked="" type="checkbox"/> Enable SNMP agent	
Name *	<input type="text" value="Conel"/>
Location *	<input type="text" value="Usti nad Orlici"/>
Contact *	<input type="text" value="Jack Roghul +420 732 123 4"/>
<input checked="" type="checkbox"/> Enable SNMPv1/v2 access	
Community	<input type="text" value="public"/>
<input type="checkbox"/> Enable SNMPv3 access	
Username	<input type="text"/>
Authentication	<input type="text" value="MD5"/>
Authentication Password	<input type="text"/>
Privacy	<input type="text" value="DES"/>
Privacy Password	<input type="text"/>
<input checked="" type="checkbox"/> Enable I/O extension	
<input type="checkbox"/> Enable XC-CNT extension	
<input checked="" type="checkbox"/> Enable M-BUS extension	
Baudrate	<input type="text" value="300"/>
Parity	<input type="text" value="even"/>
Stop Bits	<input type="text" value="1"/>
<input type="checkbox"/> Enable reporting to supervisory system	
IP Address	<input type="text"/>
Period	<input type="text"/> min
* can be blank	
<input type="button" value="Apply"/>	

Figure 50: Example of SNMP configuration




Figure 51: Example of the MIB browser

It is important to set the IP address of the SNMP agent (router) in field Remote SNMP agent. After enter the IP address is in a MIB tree part is possible show object identifier.

The path to objects is:

iso → org → dod → internet → private → enterprises → conel → protocols

The path to information about router is:


iso → org → dod → internet → mgmt → mib-2 → system

1.28 SMTP Configuration

The item *SMTP* is used for configuring SMTP (Simple Mail Transfer Protocol) client for sending e-mails.

Item	Description
SMTP Server Address	IP or domain address of the mail server.
SMTP Port	Port the SMTP server is listening on
Secure Method	none, SSL/TLS, or STARTTLS. Secure method has to be supported by the SMTP server.
Username	Name to e-mail account.
Password	Password to e-mail account. Can contain special characters * + , - . / : = ? ! # % [] _ { } ~ and can not contain special characters " \$ & ' () ; < >
Own E-mail Address	Address of the sender.

Table 58: SMTP client configuration

 Mobile operator can block other SMTP servers, then you can use only the SMTP server of operator.




Figure 52: Example of the SMTP client configuration

E-mail can be sent from the Startup script (*Startup Script* item in the *Configuration* section) or via telnet and SSH connection. The command *email* is can be used with the following parameters:


- t receiver's E-mail address
- s subject (has to be in quotation marks)
- m message (has to be in quotation marks)
- a attachment file
- r number of attempts to send email (default 2 attempts set)

 Commands and parameters can be entered only in lowercase. Example of sending an e-mail:

```
email -t name@domain.com -s "subject" -m "message" -a c:\directory\abc.doc -r 5
```

This command sends e-mail to address *name@domain.com* with the subject "*subject*", body message "*message*" and attachment "*abc.doc*" right from the directory *c:\directory* and attempts to send 5 times.

1.29 SMS configuration

 For industrial router XR5i v2 is not available SMS Configuration item.
SMS Configuration can be called up by option *SMS* item in the menu. SMS configuration defines the options for sending SMS messages from the router at different defined events and states of the router. In the first part of window it configuration send SMS.

Item	Description
Send SMS on power up	Automatic sending of SMS messages after power up.
Send SMS on connect to mobile network	Automatic sending SMS message after connection to mobile network.
Send SMS on disconnect to mobile network	Automatic sending SMS message after disconnection to mobile network.
Send SMS when datalimit exceeded	Automatic sending SMS message after datalimit exceeded.
Send SMS when binary input on I/O port (BIN0) is active	Automatic sending SMS message after binary input on I/O port (BIN0) is active. Text of message is intended parameter BIN0.
Send SMS when binary input on expansion port (BIN1 – BIN4) is active	Automatic sending SMS message after binary input on expansion port (BIN1 – BIN4) is active. Text of message is intended parameter BIN1 – BIN4.
Add timestamp to SMS	Adds time stamp to sent SMS messages. This stamp has a fixed format YYYY-MM-DD hh:mm:ss.
Phone Number 1	Telephone numbers for sending automatically generated SMS.
Phone Number 2	Telephone numbers for sending automatically generated SMS.
Phone Number 3	Telephone numbers for sending automatically generated SMS.
Unit ID	The name of the router that will be sent in an SMS.
BIN0 – SMS	SMS text messages when activate the binary input on the router.
BIN1 – SMS	SMS text messages when activate the binary input on the expansion port.

Continued on next page

Continued from previous page


Item	Description
BIN2 – SMS	SMS text messages when activate the binary input on the router.
BIN3 – SMS	SMS text messages when activate the binary input on the router.
BIN4 – SMS	SMS text messages when activate the binary input on the router.


Table 59: Send SMS configuration

In the second part of the window it is possible to set function *Enable remote control via SMS*. After this it is possible to establish and close connection by SMS message.

Item	Description
Phone Number 1	This control can be configured for up to three numbers. If is set <i>Enable remote control via SMS</i> , all incoming SMS are processed and deleted. In the default settings this parameter is turned on.
Phone Number 2	This control can be configured for up to three numbers. If is set <i>Enable remote control via SMS</i> , all incoming SMS are processed and deleted. In the default settings this parameter is turned on.
Phone Number 3	This control can be configured for up to three numbers. If is set <i>Enable remote control via SMS</i> , all incoming SMS are processed and deleted. In the default settings this parameter is turned on.

Table 60: Control via SMS configuration

 If no phone number is filled in, then it is possible to restart the router with the help of SMS in the form of Reboot from any phone number. While filling of one, two or three numbers it is possible to control the router with the help of an SMS sent only from these numbers. While filling of sign "*" it is possible control the router with the help of an SMS sent from every numbers.

 Control SMS message doesn't change the router configuration. If the router is switched to offline mode by the SMS message the router will be in this mode up to next restart. This behavior is the same for all control SMS messages.

It is possible to send controls SMS in the form:

SMS	Description
go online sim 1	Switch to SIM1 card
go online sim 2	Switch to SIM2 card

Continued on next page

Continued from previous page

SMS	Description
go online	Switch router in online mode
go offline	connection termination
set out0=0	Set output I/O connector on 0
set out0=1	Set output I/O connector on 1
set out1=0	Set output expansion port XC-CNT on 0
set out1=1	Set output expansion port XC-CNT on 1
set profile std	Set standard profile
set profile alt1	Set alternative profile 1
set profile alt2	Set alternative profile 2
set profile alt3	Set alternative profile 3
reboot	Router reboot
get ip	Router send answer with IP address SIM card

Table 61: Control SMS

By choosing *Enable AT-SMS protocol on expansion port 1* and *Baudrate* it is possible to send/receive an SMS on the serial Port 1.

Item	Description
Baudrate	Communication speed expansion port 1

Table 62: Send SMS on serial PORT1 configuration

By choosing *Enable AT-SMS protocol on expansion port 2* and *Baudrate* it is possible to send/receive an SMS on the serial Port 2.

Item	Description
Baudrate	Communication speed expansion port 2

Table 63: Send SMS on serial PORT2 configuration

By choosing *Enable AT-SMS protocol on TCP port* and enter the *TCP port* it is possible to send/receive an SMS on the TCP port. SMS messages are sent by the help of a standard AT commands.

Item	Description
TCP Port	TCP port on which will be allowed to send/receive SMS messages.

Table 64: Send SMS on ethernet PORT1 configuration

1.29.1 Send SMS

After establishing connection with the router via serial interface or Ethernet, it is possible to use AT commands for work with SMS messages.

The following table only lists the commands that are supported by Conel's routers. For other AT commands is always sent *OK* response. There is no support for treatment of complex AT commands, so in such a case router sends *ERROR* response.

AT Command	Description
AT+CGMI	Returns the manufacturer specific identity
AT+CGMM	Returns the manufacturer specific model identity
AT+CGMR	Returns the manufacturer specific model revision identity
AT+CGPADDR	Displays the IP address of the ppp0 interface
AT+CGSN	Returns the product serial number
AT+CIMI	Returns the International Mobile Subscriber Identity number (IMSI)
AT+CMGD	Deletes a message from the location
AT+CMGF	Sets the presentation format of short messages
AT+CMGL	Lists messages of a certain status from a message storage area
AT+CMGR	Reads a message from a message storage area
AT+CMGS	Sends a short message from the device to entered tel. number
AT+CMGW	Writes a short message to SIM storage
AT+CMSS	Sends a message from SIM storage location value
AT+COPS?	Identifies the available mobile networks
AT+CPIN	Is used to query and enter a PIN code
AT+CPMS	Selects SMS memory storage types, to be used for short message operations
AT+CREG	Displays network registration status
AT+CSCA	Sets the short message service centre (SMSC) number
AT+CSCS	Selects the character set
AT+CSQ	Returns the signal strength of the registered network
AT+GMI	Returns the manufacturer specific identity
AT+GMM	Returns the manufacturer specific model identity
AT+GMR	Returns the manufacturer specific model revision identity
AT+GSN	Returns the product serial number
ATE	Determines whether or not the device echoes characters
ATI	Transmits the manufacturer specific information about the device

Table 65: List of AT commands



A detailed description and examples of these AT commands can be found in the application note *AT commands*.

After powering up the router, at the mentioned the phone number comes SMS in this form:

Router (Unit ID) has been powered up. Signal strength –xx dBm.

After connect to mobile network, at the mentioned phone number comes SMS in this form:

Router (Unit ID) has established connection to mobile network. IP address xxx.xxx.xxx.xxx

After disconnect to mobile network, at the mentioned phone number comes SMS in this form:

Router (Unit ID) has lost connection to mobile network. IP address xxx.xxx.xxx.xxx

Configuration of sending this SMS is following:

SMS Configuration	
<input checked="" type="checkbox"/>	Send SMS on power up
<input checked="" type="checkbox"/>	Send SMS on connect to mobile network
<input checked="" type="checkbox"/>	Send SMS on disconnect from mobile network
<input checked="" type="checkbox"/>	Send SMS when datalimit is exceeded
<input checked="" type="checkbox"/>	Send SMS when binary input on I/O port (BIN0) is active
<input checked="" type="checkbox"/>	Send SMS when binary input on expansion port 1 (BIN1-BIN4) is active
<input checked="" type="checkbox"/>	Add timestamp to SMS
Phone Number 1	<input type="text" value="723123456"/>
Phone Number 2	<input type="text" value="756858635"/>
Phone Number 3	<input type="text" value="603854758"/>
Unit ID *	<input type="text" value="Router"/>
BIN0 - SMS *	<input type="text" value="BIN0"/>
BIN1 - SMS *	<input type="text" value="BIN1"/>
BIN2 - SMS *	<input type="text" value="BIN2"/>
BIN3 - SMS *	<input type="text" value="BIN3"/>
BIN4 - SMS *	<input type="text" value="BIN4"/>
<input checked="" type="checkbox"/>	Enable remote control via SMS
Phone Number 1	<input type="text"/>
Phone Number 2	<input type="text"/>
Phone Number 3	<input type="text"/>
<input type="checkbox"/>	Enable AT-SMS protocol on expansion port 1
Baudrate	<input type="text" value="9600"/>
<input type="checkbox"/>	Enable AT-SMS protocol on expansion port 2
Baudrate	<input type="text" value="9600"/>
<input type="checkbox"/>	Enable AT-SMS protocol over TCP
TCP Port	<input type="text"/>
* can be blank	
<input type="button" value="Apply"/>	

Figure 53: Example of SMS configuration 1

Example of the router configuration for SMS sending via serial interface on the PORT1:

SMS Configuration	
<input type="checkbox"/>	Send SMS on power up
<input type="checkbox"/>	Send SMS on connect to mobile network
<input type="checkbox"/>	Send SMS on disconnect from mobile network
<input type="checkbox"/>	Send SMS when datalimit is exceeded
<input type="checkbox"/>	Send SMS when binary input on I/O port (BIN0) is active
<input type="checkbox"/>	Send SMS when binary input on expansion port 1 (BIN1-BIN4) is active
<input type="checkbox"/>	Add timestamp to SMS
Phone Number 1	<input type="text"/>
Phone Number 2	<input type="text"/>
Phone Number 3	<input type="text"/>
Unit ID *	<input type="text"/>
BIN0 - SMS *	<input type="text"/>
BIN1 - SMS *	<input type="text"/>
BIN2 - SMS *	<input type="text"/>
BIN3 - SMS *	<input type="text"/>
BIN4 - SMS *	<input type="text"/>
<input type="checkbox"/>	Enable remote control via SMS
Phone Number 1	<input type="text"/>
Phone Number 2	<input type="text"/>
Phone Number 3	<input type="text"/>
<input checked="" type="checkbox"/>	Enable AT-SMS protocol on expansion port 1
Baudrate	<input type="text" value="9600"/>
<input type="checkbox"/>	Enable AT-SMS protocol on expansion port 2
Baudrate	<input type="text" value="9600"/>
<input type="checkbox"/>	Enable AT-SMS protocol over TCP
TCP Port	<input type="text"/>
* can be blank	
<input type="button" value="Apply"/>	

Figure 54: Example of SMS configuration 2

Example of the router configuration for controlling via SMS from every phone numbers:

SMS Configuration	
<input type="checkbox"/>	Send SMS on power up
<input type="checkbox"/>	Send SMS on connect to mobile network
<input type="checkbox"/>	Send SMS on disconnect from mobile network
<input type="checkbox"/>	Send SMS when datalimit is exceeded
<input type="checkbox"/>	Send SMS when binary input on I/O port (BIN0) is active
<input type="checkbox"/>	Send SMS when binary input on expansion port 1 (BIN1-BIN4) is active
<input type="checkbox"/>	Add timestamp to SMS
Phone Number 1	<input type="text"/>
Phone Number 2	<input type="text"/>
Phone Number 3	<input type="text"/>
Unit ID *	<input type="text"/>
BIN0 - SMS *	<input type="text"/>
BIN1 - SMS *	<input type="text"/>
BIN2 - SMS *	<input type="text"/>
BIN3 - SMS *	<input type="text"/>
BIN4 - SMS *	<input type="text"/>
<input checked="" type="checkbox"/>	Enable remote control via SMS
Phone Number 1	<input type="text" value="*"/>
Phone Number 2	<input type="text"/>
Phone Number 3	<input type="text"/>
<input type="checkbox"/>	Enable AT-SMS protocol on expansion port 1
Baudrate	<input type="text" value="9600"/>
<input type="checkbox"/>	Enable AT-SMS protocol on expansion port 2
Baudrate	<input type="text" value="9600"/>
<input type="checkbox"/>	Enable AT-SMS protocol over TCP
TCP Port	<input type="text"/>
* can be blank	
<input type="button" value="Apply"/>	

Figure 55: Example of SMS configuration 3

Example of the router configuration for controlling via SMS from two phone numbers:

SMS Configuration	
<input type="checkbox"/>	Send SMS on power up
<input type="checkbox"/>	Send SMS on connect to mobile network
<input type="checkbox"/>	Send SMS on disconnect from mobile network
<input type="checkbox"/>	Send SMS when datalimit is exceeded
<input type="checkbox"/>	Send SMS when binary input on I/O port (BIN0) is active
<input type="checkbox"/>	Send SMS when binary input on expansion port 1 (BIN1-BIN4) is active
<input type="checkbox"/>	Add timestamp to SMS
Phone Number 1	<input type="text"/>
Phone Number 2	<input type="text"/>
Phone Number 3	<input type="text"/>
Unit ID *	<input type="text"/>
BIN0 - SMS *	<input type="text"/>
BIN1 - SMS *	<input type="text"/>
BIN2 - SMS *	<input type="text"/>
BIN3 - SMS *	<input type="text"/>
BIN4 - SMS *	<input type="text"/>
<input checked="" type="checkbox"/>	Enable remote control via SMS
Phone Number 1	<input type="text" value="728123456"/>
Phone Number 2	<input type="text" value="766254864"/>
Phone Number 3	<input type="text"/>
<input type="checkbox"/>	Enable AT-SMS protocol on expansion port 1
Baudrate	<input type="text" value="9600"/>
<input type="checkbox"/>	Enable AT-SMS protocol on expansion port 2
Baudrate	<input type="text" value="9600"/>
<input type="checkbox"/>	Enable AT-SMS protocol over TCP
TCP Port	<input type="text"/>
* can be blank	
<input type="button" value="Apply"/>	

Figure 56: Example of SMS configuration 4

1.30 Expansion port configuration

Configuring of the expansion ports PORT1 and PORT2 can cause selecting *Expansion Port 1* or *Expansion Port 2*.

Item	Description
Baudrate	Applied communication speed.
Data Bits	Number of data bits.
Parity	Control parity bit <ul style="list-style-type: none"> • none – will be sent without parity • even – will be sent with even parity • odd – will be sent with odd parity
Stop Bits	Number of stop bit.
Split Timeout	Time to rupture reports. If you receive will identify the gap between two characters, which is longer than the parameter value in milliseconds. Then all of the received data compiled and sent the message.
Protocol	Protocol: <ul style="list-style-type: none"> • TCP – communication using a linked protocol TCP • UDP – communication using a unlinked protocol UDP
Mode	Mode of connection: <ul style="list-style-type: none"> • TCP server – router will listen to incoming requests about TCP connection • TCP client – router will connect to a TCP server on the specified IP address and TCP port
Server Address	In mode TCP client it is necessary to enter the Server address and final TCP port.
TCP Port	In both modes of connection is necessary to specify the TCP port on which the router will communicate TCP connections.
Inactivity Timeout	Time period after which the TCP/UDP connection is interrupted in case of inactivity

Table 66: Expansion PORT configuration 1

If the *Reject new connections* item is ticked, all other connections are rejected. This means that it is not possible to establish multiple connections.

After check *Check TCP connection*, it activates established of TCP connection.

Item	Description
Keepalive Time	Time, after which it will carry out verification of the connection
Keepalive Interval	Waiting time on answer
Keepalive Probes	Number of tests

Table 67: Expansion PORT configuration 2

When you select items *Use CD as indicator of the TCP connection* is activated function indication TCP connection using signal CD (DTR on the router).

CD	Description
Active	TCP connection is on
Nonactive	TCP connection is off

Table 68: CD signal description

When you select items *Use DTR as control of TCP connection* is activated function control TCP connection using signal DTR (CD on the router).

DTR	Description server	Description client
Active	The router allows establishing a TCP connection	Router starts TCP connection
Nonactive	The router does not permit establishing a TCP connection	Router stops TCP connection

Table 69: DTR signal description

The changes in settings will apply after pressing the *Apply* button.

Expansion Port 1 Configuration

☒ Enable expansion port 1 access over TCP/UDP
 HW flow control not supported

Port Type	RS-232
Baudrate	9600 ▼
Data Bits	8 ▼
Parity	none ▼
Stop Bits	1 ▼
Split Timeout	20 msec
Protocol	TCP ▼
Mode	server ▼
Server Address	
TCP Port	1001
Inactivity Timeout *	

☐ Reject new connections

☐ Check TCP connection

Keepalive Time	3600	sec
Keepalive Interval	10	sec
Keepalive Probes	5	

☐ Use CD as indicator of TCP connection
☐ Use DTR as control of TCP connection
** can be blank*

Figure 57: Expansion port configuration

Example of external port configuration:




Figure 58: Example of expansion port configuration 1




Figure 59: Example of expansion port configuration 2



Since firmware 3.0.9 all v2 routers provide a program called *getty* which allows user to connect to the router via the serial line (router must be fitted with an expansion port RS232!). *Getty* displays the prompt and after entering the username passes it on *login* program, which asks for a password, verifies it and runs the shell. After logging in, it is possible to manage the system as well as a user is connected via telnet.

1.31 USB port configuration

The USB port configuration can be called up by airbrush option *USB Port* in menu. Configuration can be done, if we have USB/RS232 converter.

Item	Description
Baudrate	Applied communication speed.
Data Bits	Number of data bits.
Parity	Control parity bit: <ul style="list-style-type: none"> • none – will be sent without parity • even – will be sent with even parity • odd – will be sent with odd parity
Stop Bits	Number of stop bit.
Split Timeout	Time to rupture reports. If you receive will identify the gap between two characters, which is longer than the parameter value in milliseconds. Then all of the received data compiled and sent the message.
Protocol	Communication protocol: <ul style="list-style-type: none"> • TCP – communication using a linked protocol TCP • UDP – communication using a unlinked protocol UDP
Mode	Mode of connection: <ul style="list-style-type: none"> • TCP server – router will listen to incoming requests about TCP connection • TCP client – router will connect to a TCP server on the specified IP address and TCP port
Server Address	In mode TCP client it is necessary to enter the Server address and final TCP port.
TCP Port	In both modes of connection is necessary to specify the TCP port on which the router will communicate TCP connections.
Inactivity Timeout	Time period after which the TCP/UDP connection is interrupted in case of inactivity

Table 70: USB port configuration 1

If the *Reject new connections* item is ticked, all other connections are rejected. This means that it is not possible to establish multiple connections.

After check *Check TCP connection*, it activates verification of established TCP connection.

Item	Description
Keepalive Time	Time, after which it will carry out verification of the connection
Keepalive Interval	Waiting time on answer
Keepalive Probes	Number of tests

Table 71: USB PORT configuration 2

When you select items *Use CD as indicator of the TCP connection* is activated function indication TCP connection using signal CD (DTR on the router).

CD	Description
Active	TCP connection is on
Nonactive	TCP connection is off

Table 72: CD signal description

When you select items *Use DTR as control of TCP connection* is activated function control TCP connection using signal DTR (CD on the router).

DTR	Description server	Description client
Active	The router allows establishing a TCP connection	Router starts TCP connection
Nonactive	The router does not permit establishing a TCP connection	Router stops TCP connection

Table 73: DTR signal description



Supported USB/RS232 converters:

- FTDI
- Prolific PL2303
- Silicon Laboratories CP210×(supported from firmware version 3.0.1)

The changes in settings will apply after pressing the *Apply* button

USB Port Configuration

☐ Enable USB serial converter access over TCP/UDP

Baudrate	<input type="text" value="9600"/>	▼	
Data Bits	<input type="text" value="8"/>	▼	
Parity	<input type="text" value="none"/>	▼	
Stop Bits	<input type="text" value="1"/>	▼	
Split Timeout	<input type="text" value="20"/>	msec	
Protocol	<input type="text" value="TCP"/>	▼	
Mode	<input type="text" value="server"/>	▼	
Server Address	<input type="text"/>		
TCP Port	<input type="text"/>		
Inactivity Timeout *	<input type="text"/>	sec	

☐ Reject new connections

☐ Check TCP connection

Keepalive Time	<input type="text" value="3600"/>	sec	
Keepalive Interval	<input type="text" value="10"/>	sec	
Keepalive Probes	<input type="text" value="5"/>		

☐ Use CD as indicator of TCP connection
☐ Use DTR as control of TCP connection

Figure 60: USB configuration

Example of USB port configuration:




Figure 61: Example of USB port configuration 1





Figure 62: Example of USB port configuration 2

1.32 Startup script

In the window *Startup Script* it is possible to create own scripts which will be executed after all initial scripts.

The changes in settings will apply after pressing the *Apply* button.



```
#!/bin/sh
#
# This script will be executed *after* all the other init scripts.
# You can put your own initialization stuff in here.
```


Apply

Figure 63: Startup script



Change take effect after shut down and witch on router by the help of button Reboot in web administration or by SMS message.

Example of Startup script: When start the router, stop syslogd program and start syslogd with remote logging on address 192.168.2.115 and limited to 100 entries listing.



```
Startup Script
#!/bin/sh
#
# This script will be executed *after* all the other init scripts.
# You can put your own initialization stuff in here.

killall syslogd
syslogd -R 192.168.2.115 -S 100
```


Apply

Figure 64: Example of Startup script

1.33 Up/Down script

In the window *Up/Down Script* it is possible to create own scripts. In the item *Up script* is defined scripts, which begins after establishing a PPP/WAN connection. In the item *Down Script* is defines script, which begins after lost a PPP/WAN connection.


The changes in settings will apply after pressing the *Apply* button.



The screenshot shows the 'Up/Down Script' configuration window. It has two text areas for scripts. The 'Up Script' area contains the following text: `#!/bin/sh`, `#`, and `# This script will be executed when PPP/WAN connection is established.`. The 'Down Script' area contains the following text: `#!/bin/sh`, `#`, and `# This script will be executed when PPP/WAN connection is lost.`. At the bottom of the window is an 'Apply' button.

Figure 65: Up/Down script

Example of UP/Down script: After establishing or lost a connection, the router sends an email with information about establishing or loss a connection.



The screenshot shows the 'Up/Down Script' configuration window with example email commands. The 'Up Script' area contains the following text: `#!/bin/sh`, `#`, `# This script will be executed when PPP/WAN connection is established.`, and `email -t name@domain.com -s "Conel router" -m "PPP connection is established."`. The 'Down Script' area contains the following text: `#!/bin/sh`, `#`, `# This script will be executed when PPP/WAN connection is lost.`, and `email -t name@domain.com -s "Conel router" -m "PPP connection is lost."`. At the bottom of the window is an 'Apply' button.

Figure 66: Example of Up/Down script

1.34 Automatic update configuration

In the *Automatic update* item it is possible to set the automatic configuration update. This choice enables the router to download the configuration and the newest firmware from the server automatically. The configuration and firmware files are stored on the server. To prevent possible unwanted manipulation of the files, downloaded file (tar.gz format) is controlled. At first, the format of the downloaded file is checked. Then the type of architecture and each file in the archive (tar.gz file) is controlled.

By *Enable automatic update of configuration* it is possible to enable automatic configuration update.

By *Enable automatic update of firmware* it is possible to enable firmware update.

Item	Description
Source	Where the router will download the firmware and configuration from: <ul style="list-style-type: none"> • HTTP(S)/FTP(S) server – updates are downloaded from the <i>Base URL</i> address below. Used protocol is specified by that address: HTTP, HTTPS, FTP or FTPS. • USB flash drive – Router finds current firmware or configuration in the root directory of the connected USB device. • Both – looking for the current firmware or configuration from both sources.
Base URL	Enter the base part of the domain or IP address to download the updates from. Specify the communication protocol by the address (HTTP, HTTPS, FTP or FTPS).
Unit ID	Name of configuration (name of the file without extension). If the Unit ID is not filled, the MAC address of the router is used as the filename (the delimiter colon is used instead of a dot.)
Update Hour	Use this item to set the hour (range 1-24) when the automatic update will be performed every day. If the time is not specified, automatic update is performed five minutes after turning on the router and then every 24 hours. If the detected configuration file is different from the running one, it is downloaded and the router is restarted automatically to make it run.

Table 74: Automatic update configuration

The *configuration file* name is from parameter *Base URL*, hardware MAC address of ETH0 interface and *cfg* extension. Hardware MAC address and *cfg* extension is connected automatically and it isn't needed to enter this. By parameter *Unit ID* enabled it defines the concrete configuration name which will be download to the router. When using parameter *Unit ID*, hardware MAC address in configuration name will not be used.

The *firmware file* name is from parameter *Base URL*, type of router and bin extension.



It is necessary to load two files (.bin and .ver) to the HTTP(S)/FTP(S) server. If there is uploaded only the .bin file and the HTTP server send wrong answer *200 OK* (instead of expected *404 Not Found*) when the device try to download the nonexistent .ver file, then there is a high risk that the router will download the .bin file over and over again.

The following examples find if there is a new firmware or configuration each day at 1:00 in the morning. The following example is for the ER75i v2 type of router.

- Firmware: <http://router.cz/ER75i-v2.bin>
- Configuration file: <http://router.cz/temelin.cfg>

Figure 67: Example of automatic update 1

The following examples find if there is a new firmware or configuration each day at 1:00 in the morning. The following example is for ER75i v2 with MAC address 00:11:22:33:44:55.

- Firmware: <http://router.cz/ER75i-v2.bin>
- Configuration file: <http://router.cz/00.11.22.33.44.55.cfg>

Figure 68: Example of automatic update 2



Firmware update can cause incompatibility of the user modules. It is recommended to update user modules to the most recent version. Information about the user module and the firmware compatibility is at the beginning of the user module's Application Note.

1.35 User modules

Configuration of user modules can be accessed by selecting the *User Modules* item. It is possible to add new modules, delete them or switch to their configuration. Use the *Browse* button to select the user module (compiled module has tgz extension). The module is added using the *Add* button.

The screenshot shows a web interface titled "User Modules". Below the title bar, it states "No user modules installed." At the bottom, there is a "New Module" text input field, followed by two buttons: "Procházet..." and "Add".

Figure 69: User modules

Added module appears in the list of modules on the same page. If the module contains index.html or index.cgi page, module name serves as a link to this page. The module can be deleted using the *Delete* button.

Updating of the module can be done in the same way like adding a new module. Module with a higher (newer) version will replace the existing module. The current module configuration is kept in same state.

Programming and compiling of modules are described in the programming guide.

The screenshot shows the "User Modules" interface with a list of installed modules. One module is listed: "Example 1.0.0 (2011-05-30)" with a "Delete" button next to it. At the bottom, the "New Module" input field and "Procházet..." and "Add" buttons are still visible.

Figure 70: Added user module

There are for example these user's modules:


Module name	Description
MODBUS TCP2RTU	Provides a conversion of MODBUS TCP/IP protocol to MDBUS RTU protocol, which can be operated on the serial line.
Easy VPN client	Provides secure connection of LAN network behind our router with LAN network behind CISCO router.
NMAP	Allows to do TCP and UDP scan.
Daily Reboot	Allows to perform daily reboot of the router at the specified time.
HTTP Authentication	Adds the process of authentication to a server that doesn't provide this service.
BGP, RIP, OSPF	Add support of dynamic protocols.
PIM SM	Adds support of multicast routing protocol PIM-SM.

Continued on next page

Continued from previous page

Module name	Description
WMBUS Concentrator	Allows to receive messages from WMBUS meters and saves contents of these messages to XML file.
pduSMS	Sends short messages (SMS) to specified number.
GPS	Allows v2 router to provide location and time information in all weather, anywhere on or near the Earth, where there is an unobstructed line of sight to four or more GPS satellites.
Pinger	Allows to manually or automatically verify the functionality of the connection between two network interfaces (ping).
IS-IS	Add support of IS-IS protocol.

Table 75: User modules

 Attention, in some cases the firmware update can cause the incompatibility of used user modules. Some of them are dependent on the version of linux kernel (e.g. *SmsBE* and *PoS Configuration*). It is recommended to update user modules to the most recent version. Information about the user module and the firmware compatibility is at the beginning of the user module's Application Note.

1.36 Change profile

To open the dialog box for changing profile select the *Change Profile* menu item. Profile switch is making by press the button *Apply*. Change take effect after restarting router by the help of button *Reboot* in web administration or by SMS message. It is possible select the standard profile or up to three alternative profiles. It is possible to copy actual configuration to selected configuration by selecting *Copy settings from current profile to selected profile*.

Example of usage profiles: Profiles can be used for example to switch between different modes of operation of the router (router has compiled a connection, the router has not compiled a connection and the router creates a tunnel to the service center). Change the profile can then be done using a binary input, SMS or Web interface of the router.



Figure 71: Change profile

1.37 Change password



To change the access password, select the *Change Password* menu item.

In basic settings of the router the password is set on *root* in default. **For the security of your network it is necessary to change this default password.**



Type the new password twice and save it by pressing the *Apply* button.

Only the first 8 characters of the password are used for the authentication. Longer passwords are meaningless. This is the standard Unix Crypt mechanism. It won't be possible to enable the remote access to the router (in NAT) until the change of the password is done.

Change Password	
New Password	<input type="text"/>
Confirm Password	<input type="text"/>
<input type="button" value="Apply"/>	

Figure 72: Change password

1.38 Set real time clock

Disposable setting of the router internal clock can be invoked by pressing the *Set Real Time Clock* item in the main menu of the web interface. Date and time can be set manually through the *Date* and *Time* items. Always enter data in a format that is illustrated in the figure below. The clock can be also adjusted according to the specified NTP server. Finally, it is necessary to press the *Apply* button.

Set Real Time Clock	
Date	<input type="text" value="2013 - 07 - 08"/>
Time	<input type="text" value="12 : 50 : 17"/>
NTP Server Address	<input type="text"/>
<input type="button" value="Apply"/>	

Figure 73: Set real time clock

1.39 Set SMS service center address



For industrial router XR5i v2 is not available Set SMS service center address item.

In some cases it is needed to set the phone number of the SMS service centre because of SMS sending. This parameter can not be set when the SIM card has set phone number of the SMS service centre. The phone number can be formed without international prefix xxx xxx xxx or with international prefix for example +420 xxx xxx xxx.




Figure 74: Set SMS service center address

1.40 Unlock SIM card



For industrial router XR5i v2 is not available Unlock SIM card item.



Possibility to unlock SIM PIN is under *Unlock SIM Card* item. If the inserted SIM card is secured by a PIN number, enter the PIN to field *SIM PIN* and push-button *Apply*.

SIM card is blocked after three failed attempts to enter the PIN code.




Figure 75: Unlock SIM card

1.41 Send SMS



For industrial router XR5i v2 is not available Send SMS item.

Sending SMS messages is possible in menu *Send SMS*. The SMS message will be sent after entering the *Phone number* and text SMS (*Message*) and by pushing button *Send*. Maximal length of the SMS is 160 characters (to send longer SMS use e.g. the *pduSMS* user module).



Figure 76: Send SMS

SMS message sending via HTTP request is in the form:

```
GET/send_exec.cgi?phone=%2B420712345678&message=Test HTTP/1.1
Authorization: Basic cm9vdDpyb290
```

HTTP request will be sent to TCP connection on router port 80. Router sends an SMS message with text "Test". SMS is sent to phone number "420712345678". Authorization is in the format "user:password" coded by BASE64. In the example is used for root:root.

1.42 Backup configuration

The router configuration is possible to save by help of the *Backup Configuration* menu item. After clicking on this menu it is possible to check a destination directory, where it will save the router configuration.

1.43 Restore configuration

In case it is needed to restore the router configuration, it is possible in *Restore Configuration* menu item to check configuration by help *Browse* button.



Figure 77: Restore configuration

1.44 Update firmware

To view the information about the firmware version and instructions for its update select the *Update Firmware* menu item. New firmware is selected via Browse button and update the following pressing the Update button.



Figure 78: Update firmware

After successful firmware updating the statement about FLASH memory is listed:

```
Uploading firmware to RAM... ok
Programming FLASH..... ok

Reboot in progress
Continue here after reboot.
```



Upload firmware of different device can cause damage of the router! During updating of the firmware permanent power supply has to be maintained.



Starting with FW 5.1.0 mechanism to prevent multiple startup of firmware update is added.



Firmware update can cause incompatibility of the user modules. It is recommended to update user modules to the most recent version. Information about the user module and the firmware compatibility is at the beginning of the user module's Application Note.

1.45 Reboot

To reboot the router select the *Reboot* menu item and then press the *Reboot* button.



Figure 79: Reboot

2. Configuration over Telnet

Attention! If the SIM card isn't inserted in the router, it is impossible for the router to operate. The Included SIM card must be activated for GPRS transmissions.

Monitoring of status, configuration and administration of the router can be performed by means of the Telnet interface. After IP address entry to the Telnet it is possible to configure the router by the help of commands. The default IP address of the modem is 192.168.1.1. Configuration may be performed only by the user "root" with initial password "root".

For Telnet exists the following commands:

Command	Description
cat	file contain write
cp	copy of file
date	show/change of system time
df	displaying of informations about file system
dmesg	displaying of kernel diagnostics messages
echo	string write
email	Email send
free	displaying of informations about memory
gsmat	sends AT commands (<i>cdmaat</i> for routers with CDMA module)
gsminfo	displaying of informations about signal quality
gsmsms	SMS send
hwclock	displaying/change of time in RTC
ifconfig	displaying/change of interface configuration
io	reading/writing input/output pins
ip	displaying/change of route table
iptables	displaying/modification of NetFilter rules
kill	process kill
killall	processes kill
ln	link create
ls	dump of directory contain
mkdir	file create
mv	file move
ntpdate	synchronization of system time with NTP server

Continued on next page

Continued from previous page

Command	Description
passwd	password change
ping	ICMP ping
ps	displaying of processes information
pwd	dump of actual directory
reboot	reboot
rm	file delete
rmdir	directory delete
route	displaying/change of route table
service	start/stop of service
sleep	pause on set seconds number
slog	displaying of system log
tail	displaying of file end
tcpdump	monitoring of network
touch	file create/actualization of file time stamp
vi	text editor

Table 76: Telnet commands